

iPAQ

System Boards	Assembly	Spare Part
System Board	011010-101	226786-001
System Board, Celeron	161015-002	166364-001
System Board, Celeron, Legacy Free	161014-002	166362-001
System Board, Pentium, w/ Cache Lite, 4M	161015-001	166363-001
System Board, Pentium, Legacy Free, w/o Cache, 4M	161014-001	166361-001

Note: To avoid injury from electric shock and/or hot surfaces, unplug the AC power cord from the wall outlet and allow the internal components of the PC to cool before servicing the unit.

Configuration Code	Assembly	System Board Spare Part
DZD2	161015-002	166364-001
DZD4	161015-002	166364-001
DZD5	161015-002	166364-001
DZF2	161014-002	166362-001
DZG3	161015-001	166363-001
DZG4	161015-001	166363-001
DZG5	161015-001	166363-001
DZH2	161014-001	166361-001
DTMZ		CTO
FTD2	161014-001	166361-001
FTD3	161014-001	166363-001
FTD4	161014-001	166363-001

Microprocessors	Assembly	Spare Part
500/100 MHz uP w/ Heat Sink, Celeron		166366-001
500/133 MHz uP w/ Heat Sink, Pentium		166365-001
700/66 MHz, Celeron	174029-106	230788-001
733/133 MHz w/ Heat Sink	158807-010	212566-001
800/100 MHz	230357-001	235024-001
866/133 MHz, CuMine	158807-305	231784-001
933/133 MHz, CuMine	158807-311	239421-001

Memory	Assembly	Spare Part
32 MB Memory Module	323029-001	166890-001
64 MB Memory Module	323012-001	179190-001
64 MB, PC 133, SDIMM	168694-001	170080-001
128 MB Memory Module	323013-001	166966-001
128 MB, PC 133, SDIMM	168695-001	170081-001
256 MB Memory Module	165053-001	141009-001
256 MB, PC 133, DIMM, SDRAM	140134-001	192014-001

Miscellaneous	Assembly	Spare Part
Bezel Blank, Carbon	159420-002	231612-001
Brace		228744-001
Brace, Hard Drive	170512-001	174440-001
Cable Assembly, MultiBay Items	159686-001	170226-001
Cable Assembly, Speaker		170232-001
Cable Assembly, Unit Hard Drive	108950-020	170225-001
Cable, Dual Conn, IDE	108950-029	228741-001
Feet, Rubber, (10 each)		141332-001

Continued

iPAQ

Miscellaneous	Assembly	Spare Part
Grill, Speaker – SK	159569-001	170230-001
Hardware Kit, Security	191715-001	195505-001
Heat Sink	215893-002	230005-001
Heat Sink, Forged, 1 GHz, SP	233605-001	239422-001
Keyboard, Internet, Carbon	122659-008	164996-001
Keyboard, Internet, Carbon, CH	126739-118	173347-111
Keyboard, Internet, Carbon, DE	126739-048	173347-041
Keyboard, Internet, Carbon, FR	126739-058	173347-051
Keyboard, Internet, Carbon, GB	126739-038	173347-031
Keyboard, Internet, Carbon, PS/2		164996-xx1
Keyboard, Internet, Carbon, SE	126739-108	173347-101
Keyboard, Internet, Carbon, US	126739-008	173347-001
Keyboard, Internet, Carbon, USB		222860-xx1
Keyboard, Internet, PS/2, Carbon, JP	126739-198	173347-191
Keyboard, Internet, USB, Carbon, CH	162989-118	164995-111
Keyboard, Internet, USB, Carbon, DE	162989-048	164995-041
Keyboard, Internet, USB, Carbon, EAK	170258-008	222860-001
Keyboard, Internet, USB, Carbon, FR	162989-058	164995-051
Keyboard, Internet, USB, Carbon, GB	162989-038	164995-031
Keyboard, Internet, USB, Carbon, JP	162989-291	164995-191
Keyboard, Internet, USB, Carbon, SE	162989-108	164995-101
Keyboard, Internet, USB, Carbon, US	162989-008	164995-001
Module Legacy Board	224922-001	231611-001
Module Legacy Board		228025-001
Mouse, PS/2, Carbon	334684-008	165000-001
Mouse, USB, Carbon	155161-008	164999-001
Multibay Bezel Blank	159420-001	174441-001
Multibay Module Board	011059-101	218593-001
Optic Paper Sensor		154761-001
PCA, MultiBay Connector	010644-001	170227-001
PCA, USB/Audio Connector	010650-001	170229-001
Panel Side, Left and Right	221016-001	228743-001
Plastic, Front Bezel and Cable (includes power-on PCA)		170231-001
Plastic, Front Speaker Grill	159569-001	170230-001
Plastic, Removable Sides (2), Left and Right		170234-001
Plastic, Top Vent, Carbon	159351-001	170233-001
Riser MBAY Board		170227-002
Security Bracket	221004-001	230008-001
Security Brackets/10	191715-001	210505-001
Security Brackets/50	191715-001	217153-001
Video Cache Board	011044-101	226615-001

MultiBay Devices	Assembly	Spare Part
2X LS-120 Diskette		230009-001
CD-ROM, 24X	401998-001	100044-001
CD-ROM, 24X	314933-399	228746-001
CD RW UPG, All	201090-001	153992-001
DVD-ROM, 4X	388836-390	102266-001
		Replaced w/ 173949-001
LS-120 SuperDisk	305824-333	174129-001
Zip Drive, 250 MB		218683-001
Zip Drive, 250 MB, Slim, CBN	201091-730	221759-001

iPAQ

Hard Drives	Assembly	Spare Part
4.32 GB, 3.5", DPS	158738-001	161431-001
6.0 GB, Including Cradle	168820-001	174089-001
8.4 GB, 3.5", DPS	158739-001	163804-001
10.0 GB, 2.5", MBAY	176005-028	220994-001
10.0 GB, 5400 rpm	173339-001	197797-001
10.0 GB, 5400 Quiet	173339-001	203139-001
Hard Drive Adapter	147502-001	175369-001


Battery/Power Supply	Assembly	Spare Part
Battery, 3V Lithium	298031-001	234556-001
Battery, 770 Disc, LI/MN02, 3V	166899-001	153099-001
Power Supply, 90W	159447-001	163555-001
Power Supply, 110W, 3.3V, 5V, AUX	216922-001	218980-001
Power Supply, 110W, 3.3V, 5V, AUX	218584-001	224054-001

Options	Option Part	Assembly	Spare Part
CD-ROM, 24X	165864-B21	314933-399	228746-001
CD-ROM, 20X, Read/Write, Opal	201808-B21	178373-133	203628-001 Replaced w/ 153992-001
CD-ROM, 24X, MultiBay	165864-B21	401999-001	100044-001
Diskette Drive, LS-120, 2X	165866-B21	189503-001	201274-001
DVD-ROM, 4X, Carbon	165865-B21	388836-390	102266-001 Replaced w/ 173949-001
DVD-ROM, 8X	202994-B21	174145-001	173949-001
Hard Drive, 6 GB, MultiBay	165861-B21	386916-001	174089-001
Modem, 56K, USB, Data/Fax		322079-B21	322075-B21
Speakers, 40X70, 12"		174921-002	192518-001
Speakers, Carbon - US	173888-001	173888-001	173980-001
Speakers, PS115, OP, w/ Adapter, EURO	173888-002		173980-022
Speakers, PS115, OP, w/ Adapter, UK	173888-031		173980-031


iPAQ

Memory Upgrade Chart

SYSTEM BOARDS
161014-00X
161015-00X



MAXIMUM MEMORY 512 MB



32-MB 100 MHz SDRAM DIMMs	OPTION PN 166612-B21
64-MB 100 MHz SDRAM DIMMs	OPTION PN 166613-B21
128-MB 100 MHz SDRAM DIMMs	OPTION PN 166614-B21
256-MB 100 MHz SDRAM DIMMs	OPTION PN 102306-B21