

This is what you have to enter for a Hayes 2400 baud modem for Xenix. Each command is followed by a <cr>.

AT&F Load factory default settings  
ATT Tone Dialing  
ATL1 Low Volume  
AT&D2 On Hook when DTR drops  
AT&C1 Carrier Detect tracks Carrier  
ATS0=1 Auto-answer on first ring  
ATE0 Dont echo commands  
ATQ1 Quit mode. Don't echo OK.  
AT&W Store above in CMOS RAM

~~car care~~

car care

SCO 044111

SCWV6Rpg

