

AIX 5L Version 5.1



AIX Installation in a Partitioned Environment Guide

AIX 5L Version 5.1



AIX Installation in a Partitioned Environment Guide

Second Edition (April 2002)

Before using the information in this book, read the general information in “Notices” on page 59.

This edition applies to AIX 5L Version 5.1 and to all subsequent releases of this product until otherwise indicated in new editions.

© Copyright International Business Machines Corporation 2001, 2002. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

About This Book	v
Who Should Use This Book	v
Highlighting	v
ISO 9000	v
Related Publications	v
Trademarks	vi
Chapter 1. Getting Started	1
eServer pSeries Materials	2
Documentation Overview	2
Configuring Online Documentation.	4
Viewing the online documentation from the Documentation CD	4
Installing the online documentation on a system.	4
Installing the Online Documentation on a Documentation Server.	4
Chapter 2. Overview of Partitioning	5
Managed System	5
Logical Partitions	5
Affinity Logical Partitions	5
Full System Partition.	6
Working with Logical Partitions	6
Partition Roadmap	7
When to Implement Logical Partitions	7
Server Consolidation.	7
Mixed Production and Test Environments	7
Consolidation of Multiple Versions of the Same Operating System	8
Chapter 3. Logical Partition Scenarios and Recommendations	9
Overview of AIX Installation Process	9
Introduction to Network Installation Management	9
Installation Scenarios	12
Updating an Existing AIX 5.1 System	12
First AIX System in Your Environment	12
Migrating to AIX 5.1 and Configuring Partition Support	13
Installing a Partition Using Alternate Disk Installation	13
Adding Your Managed System to an RS/6000 SP Environment.	13
Advanced Installation Options	13
Chapter 4. Installing AIX in a Partitioned Environment	15
Step-by-Step: Using a Separate AIX System as a NIM Master to Use NIM to Install Each Partition	16
Prerequisites	16
1. Configure NIM Master and Initiate Installation of Partitions (Perform These Steps in the AIX Environment)	16
2. Activate and Install Partitions (Perform These Steps in the HMC Interface)	19
3. Log in to Your Partition (Perform this step in the AIX environment)	22
Step-by-Step: Configuring an Initial Partition as a NIM Master to Use NIM to Install the Remaining Partitions.	23
Prerequisites	23
1. Activate the Master_LPAR (Perform this Step in the HMC Interface)	23
2. Configure NIM Master and Initiate Installation of Partitions (Perform These Steps in the AIX Environment)	24
3. Activate and Install Partitions (Perform these steps in the HMC Interface)	27
4. Log in to Your Partition (Perform this step in the AIX environment)	29

Step-by-Step: Using the CD Device to Manually Install a Partition.	30
Prerequisites	30
1. Activate and Install the Partition (Perform These Steps in the HMC Interface)	30
2. Manage Your Partition (Perform This Step in the AIX Environment)	34
Step-by-Step: Migrating a System to the AIX 5.1 Partition-Ready State	36
Prerequisites	36
1. Migrate the System to AIX 5.1 (Perform in the AIX Environment)	36
2. Manage Your Migrated System (Perform this Step in the AIX Environment)	38
Step-by-Step: Updating a Partition to the AIX 5.1 Partition-Ready State	39
Prerequisites	39
1. Update Your AIX 5.1 Partition (Perform in the AIX environment)	39
2. Manage Your Partition (Perform this Step in the AIX Environment)	39
Step-by-Step: Updating an Existing NIM Environment to the Latest AIX 5.1 Maintenance Level	40
Prerequisites	40
1. Update Your AIX 5.1 NIM Environment to the Latest Maintenance Level (Perform in the AIX Environment)	40
2. Manage Your Partition (Perform this Step in the AIX Environment)	41
Chapter 5. System Backup, Dump, and Storage Management	43
System Backup	43
Creating a System Backup	43
Installing a System Backup Using NIM.	46
System Dump Management	48
Storage Management	51
Chapter 6. Remote Management	53
Remote Management From the HMC to AIX Partitions	53
Chapter 7. Hints and Tips	55
Naming Your Operating System Host Name.	55
Network Adapter Communication Between Partitions and the HMC	55
Shutting Down a Partition	56
Using AIX to Shut Down a Partition	57
Using the HMC Interface to Shut Down a Partition	57
Appendix. Notices.	59
Index	61

About This Book

This book describes different ways to install the AIX 5L Version 5.1 operating system in a partitioned environment, including using a CD-ROM device to install AIX and the Network Installation Management interface.

Before continuing, ensure that the service representative has completed the following tasks:

- Installation of all hardware components of the IBM @server pSeries managed system
- Configuration of the Hardware Management Console (HMC)

If either of these processes has not been completed, contact your service representative.

To learn more about the planning issues associated with creating logical partitions, see the *IBM Hardware Management Console for pSeries Operations Guide* for information on the following tasks:

- Preparing for Logical Partitioning
- Partition Management
- Logical Partitioning Mode Tasks

Who Should Use This Book

This guide is for system administrators who manage the installation, configuration, and maintenance of one or more logical partitions running the AIX operating system. Readers should be familiar with the installation concepts, understand AIX system administration, and know how to manage a network environment.

Highlighting

The following highlighting conventions are used in this book:

Bold	Identifies commands, subroutines, keywords, files, structures, directories, and other items whose names are predefined by the system. Also identifies graphical objects such as buttons, labels, and icons that the user selects.
<i>Italics</i>	Identifies parameters whose actual names or values are to be supplied by the user.
Monospace	Identifies examples of specific data values, examples of text similar to what you might see displayed, examples of portions of program code similar to what you might write as a programmer, messages from the system, or information you should actually type.

ISO 9000

ISO 9000 registered quality systems were used in the development and manufacturing of this product.

Related Publications

The following publications contain related information:

- *IBM Hardware Management Console for pSeries Operations Guide*
- *AIX 5L Version 5.1 Installation Guide*
- *AIX 5L Version 5.1 Network Installation Management Guide and Reference*
- *AIX 5L Version 5.1 System Management Guide: Operating System and Devices*
- *AIX 5L Version 5.1 System Management Guide: Communications and Networks*
- *AIX 5L Version 5.1 Commands Reference*
- *AIX 5L Version 5.1 Files Reference*

- *AIX 5L Version 5.1 General Programming Concepts: Writing and Debugging Programs*
- *AIX 5L Version 5.1 System User's Guide: Operating System and Devices*
- *AIX 5L Version 5.1 System User's Guide: Communications and Networks*

Trademarks

The following terms are trademarks of International Business Machines Corporation in the United States, other countries, or both:

- AIX
- AIX 5L
- IBM
- e(logo)
- PowerPC
- pSeries
- RS/6000
- SP

UNIX is a registered trademark of The Open Group in the United States and other countries.

Java and all Java-based trademarks and logos are registered trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.


Other company, product, or service names may be the trademarks or service marks of others.

Chapter 1. Getting Started

This chapter helps you get started with installing and configuring an eServer pSeries managed system environment. The following information is included in the chapter:

- eServer pSeries Roadmap
- eServer pSeries Materials - List of eServer pSeries materials
- Documentation Overview - Brief description of the printed and softcopy documentation shipped including targeted audience
- Configuring Online Documentation - How to install and view the online documentation

The eServer pSeries Roadmap helps you locate marketing, service, and customer task information. The roadmap guides you through the tasks and the publications that document those tasks.



eServer pSeries Materials

Based on your order request, the eServer pSeries shipment may include the following materials:

CD-ROM Media

- AIX 5L Version 5.1 CDs
- AIX 5L Bonus Pack
- AIX 5L Expansion Pack
- AIX 5L Documentation CD

Documentation Guides

- eServer pSeries Installation Guide
- IBM Hardware Management Console for pSeries Operations Guide
- AIX Installation in a Partitioned Environment Guide
- AIX 5L Version 5.1 Installation Guide
- AIX 5L Version 5.1 Network Installation Management Guide and Reference
- AIX 5L Version 5.1 Release Notes
- eServer pSeries User's Guide
- PCI Adapter Placement Reference
- System Unit Safety Information
- Electronic Service Agent for eServer pSeries RS/6000

Documentation Overview

This section provides descriptions, and target audience information for the eServer pSeries and AIX 5L documentation libraries. Some of the documentation may only be available in printed form or in softcopy form. Based on the documentation content, the books are divided into the following categories: **Planning**, **Installing and Configuring**, and **Using the System**. The documentation listed as being available as softcopy can also be found on the Internet at the following Web address:

<http://www-1.ibm.com/servers/eserver/pseries/library/>

Table 1. Planning

Documentation Title	Description	Audience	Type
Site and Hardware Planning Information	Contains information to help plan for site preparation tasks, such as floor-planning, electrical needs, air conditioning, and other site-planning considerations.	Marketing, system administrators	softcopy
IBM Hardware Management Console for pSeries Operations Guide	Provides information on how to configure and use a Hardware Management Console (HMC). Logical partition (LPAR) and affinity logical partitions tasks, such as configuring and managing partitions are included.	System administrators	printed and softcopy

Table 2. Installing and Configuring

Documentation Title	Description	Audience	Type
eServer pSeries Installation Guide	Provides information on how to install system hardware, cable the system, and verify operations.	Service personnel	printed and softcopy

Table 2. Installing and Configuring (continued)

IBM Hardware Management Console for pSeries Operations Guide	Provides information on how to configure and use an HMC. Partition tasks, such as setting up partitions for booting in the System Management Services (SMS) interface, Normal mode, or Diagnostic mode are included.	System administrators	printed and softcopy
AIX Installation in a Partitioned Environment	Provides guidance and procedures on how to install AIX in a partitioned environment.	System administrators	printed and softcopy
AIX 5L Installation Guide	Provides information on how to install, manage, and maintain the AIX 5L operating system.	System administrators	printed and softcopy
AIX 5L Network Installation Management Guide and Reference	Provides detailed information about using Network Installation Management (NIM) to install the AIX 5L operating system.	System administrators	printed and softcopy
PCI Adapter Placement Reference	Outlines system-specific PCI adapter slot placement and adapter support configurations.	Service personnel	printed
AIX 5L Release Notes	Provides late-breaking information for a specific AIX release.	System administrators	printed and softcopy
AIX 5L Documentation CD	AIX documentation library (system management guides, user guides, application programmer guides, commands and files references, AIX man pages, and so on).	System administrators	softcopy

Table 3. Using the System

Documentation Title	Description	Audience	Type
IBM Hardware Management Console for pSeries Operations Guide	Provides information on how to configure and use an HMC. Partition tasks, such as configuring and managing partitions are included.	System administrators	printed and softcopy
eServer pSeries User's Guide	Provides using, problem determination, and service processor information.	System administrators	printed and softcopy
eServer pSeries Service Guide	Contains MAPs, removal and replacement, error code, and parts information to help diagnose and repair the system. Also contains MAPs that are not common to all systems.	Service personnel	printed and softcopy
Diagnostic Information for Multiple Bus Systems	Combines operating instructions for hardware diagnostic programs with common MAPs and SRNs (Service Request Numbers).	Service personnel	printed and softcopy
PCI Adapter Placement Reference	Outlines system-specific PCI adapter slot placement and adapter support configurations.	Service personnel	printed
Hardware Management Console for pSeries Maintenance Guide	Contains MAPs, removal and replacement, error code, and parts information to help diagnose and repair the system.	Service personnel	printed and softcopy
Adapters, Devices, and Cable Information for Multiple Bus Systems	Provides information about adapters, devices, and cables that are attached to or used within the system.	System administrators	printed and softcopy
System Unit Safety Information	Contains the English version of safety notices, as well as translations of those safety notices into other languages.	System administrators, service personnel	printed and softcopy

Table 3. Using the System (continued)

AIX 5L Documentation CD	AIX documentation library (system management guides, user guides, application programmer guides, commands and files references, AIX man pages, and so on).	System administrators	softcopy
-------------------------	--	-----------------------	----------

Configuring Online Documentation

It is not necessary to install the operating system's online documentation onto your server. You can access all of the documentation through the Internet at the following Web address:

<http://www.ibm.com/servers/aix/library/techpubs.html>

However, if you use the Documentation Library Service to search any online documentation, it searches only the registered documentation that is installed. It does not search the documentation at the above Web site.

Viewing the online documentation from the Documentation CD

To view the online documentation, you must have an HTML browser installed on your system. The Netscape browser is located on the AIX 5L Expansion Pack.

Installing the online documentation on a system

1. Insert the AIX Documentation CD in the CD device.
2. Type **smitty install_latest**.
3. Select or type the CD device containing the AIX Documentation CD in the field provided and press Enter.
4. In the Install Software menu, use the F4 key to list the documentation packages and filesets that are available to install. Select a package or fileset by highlighting the appropriate choice and pressing the F7 key. Press Enter when finished making your selections.
5. Select the appropriate responses for the remaining questions in the Install Software menu or accept the default choices. When you are done, press Enter. From the confirmation menu, press Enter to install the software.
6. Press F10 to exit the SMIT menu and return to the command line.

Installing the Online Documentation on a Documentation Server

For detailed information on how to install and configure a documentation server and install the documentation, refer to the Using the Documentation Library Service section in the *AIX 5L Installation Guide*.

Chapter 2. Overview of Partitioning

Partitioning your system is similar to partitioning a hard drive. When you partition a hard drive, you divide a single physical hard drive so that the operating system recognizes it as a number of separate logical hard drives. You have the option of dividing the system's resources by using the HMC to partition your system. On each of these divisions, called partitions, you can install an operating system and use each partition as you would a separate physical system.

Managed System

A managed system is a system that is physically attached to and managed by the HMC. The HMC can perform tasks that affect the entire managed system, such as powering the system on and off. You can also create partitions and partition profiles within each managed system. These partitions and partition profiles define the way that you configure and operate your partitioned system.

Logical Partitions

A *logical partition* (LPAR) is the division of a computer's processors, memory, and hardware resources into multiple environments so that each environment can be operated independently with its own operating system and applications. The number of logical partitions that can be created depends on the system's processor model and resources available. Typically, partitions are used for different purposes, such as database operation, client/server operations, Web server operations, test environments, and production environments. Each partition can communicate with the other partitions as if each partition is a separate machine.

Beginning with AIX 5.1, the AIX operating system supports partitioned environments. Although the AIX installation concepts are the same, the configuration and management of a partitioned environment with the AIX operating system are new. This guide assumes the reader has some familiarity with partition management. Refer to the *IBM Hardware Management Console for pSeries Operations Guide* for more information about partition management.

A logical partition must contain a minimum set of resources, as follows:

- 1 GB of available system memory
- One available system processor
- One boot device on an assigned I/O slot
- One available network adapter (for error reporting)
- Any other adapters you may need on an assigned I/O slot

Processors, memory, and I/O slots can be allocated to any partition, regardless of their location. However, if you attempt to activate a partition, but the resources you specified are not available at the time, partition activation fails. It is important to keep track of your system's resources to avoid activation failures. PCI slots are assigned individually to partitions, and memory can be allocated in 256 MB increments. The granularity of the resources that can be assigned to partitions is very fine, providing flexibility to create systems with just the desired amount of resources. Each partition runs its own copy of the AIX operating system and is isolated from any activity in other partitions. Software failures do not propagate through the system, and the hardware facilities and microcode isolate the resources.

Affinity Logical Partitions

Some systems have the ability to create affinity logical partitions. Check your hardware specifications to see if your managed system is capable of utilizing affinity logical partitions. An affinity logical partition is a special type of logical partition that uses system resources that are in close physical proximity to each other. When creating an affinity logical partition, the HMC automatically determines which system

resources are to be used, based on their physical location to each other. The system resources that are automatically managed by the HMC are processors and memory. The user determines the I/O requirements for each of these partitions. The HMC then creates a profile for each affinity logical partition and a system profile for the managed system.

Full System Partition

A special partition called the Full System Partition assigns all of your managed system's resources to one large partition. The Full System Partition is similar to the traditional, non-partition method of operating a system. Because all resources are assigned to this partition, no other partitions can be started when the Full System Partition is running. Likewise, the Full System Partition cannot be started while other partitions are running. It is recommended that you choose to use either the Full System Partition or create other partitions. It is not recommended that you switch between these two options frequently, because your I/O usage might be affected.

Working with Logical Partitions

The logical partition resource allocation provides the ability to select individual components to be added to a partition without dependencies between these resources. The slots can be freely allocated in any I/O drawer on the system. Other devices may be required for specific application requirements. It is a good idea to configure more PCI slots in the partition than are required for the number of adapters. This provides flexibility by allowing additional adapters to be hot-plugged into the empty slots that are part of an active partition. Because each partition requires its own separate boot device, the system must have at least one boot device and associated adapter per partition.


There are a few differences in how AIX runs within a logical partition, as opposed to how it runs on a standalone server:

- In order for AIX to run inside a logical partition, AIX calls the Hypervisor in place of its traditional direct access to the hardware and address-mapping facilities.
- Some direct-access calls are presented for diagnostic purposes, and alternate return codes for Run-Time Abstraction Services (RTAS) calls are used whenever an illegal operation is issued.
- No physical console exists on the partition. While the physical serial ports on the system can be assigned to the partitions, they can only be in one partition at a time. To provide an output for console messages and also for diagnostic purposes, the firmware implements a virtual tty that is seen by AIX as a standard tty device. Its output is sent to the HMC. The AIX diagnostics subsystems use the virtual tty as the system console.
- Certain platform operations are constrained in LPARs. For example, in non-LPAR systems, platform firmware updates can be performed from AIX by a root user. Because firmware updates can affect all partitions in an LPAR system, the LPAR administrator can specify that a particular partition (or no partition) has this authority. Within that partition, firmware updates work in the same way as they do for non-LPAR systems.

Apart from these considerations, AIX runs within a partition the same way it runs on a standalone server. No differences are observed either from the application or the administrator's points of view. In fact, third-party applications need only be certified for a level of AIX that runs in a partition, and *not* for the LPAR environment itself. In this way, a logically partitioned system can be viewed as another pSeries hardware-platform environment.

Partition Roadmap

Use the following illustration to help you locate information about understanding, planning for, and configuring partitions, as well as information about installing the AIX operating system.



When to Implement Logical Partitions

A logically partitioned environment adds to a portfolio of solutions that can provide better management, improved availability, and more efficient use of resources. This section provides some scenarios where a logically partitioned environment brings significant benefits, as well as other scenarios where it may not be appropriate.

Server Consolidation

A server with sufficient processing capacity that is capable of being partitioned can address the need for server consolidation by logically subdividing the server into a number of separate smaller systems. In this way the application-isolation needs can be met in a consolidated environment, with the additional benefits of reduced floor space, a single point of management, and easier redistribution of resources as workloads change.

Mixed Production and Test Environments

Generally, production and test environments should be isolated from each other. Partitioning enables separate partitions to be allocated for the production and test systems, eliminating the need to purchase additional hardware and software. When testing has been completed, the resources allocated to the test partition can be returned to the production partition or elsewhere as required. It might be that the test environment later becomes the production environment, and extra resources can then be added to the partition. As new projects are developed, they can be built and tested on the same hardware on which they will eventually be deployed.

Consolidation of Multiple Versions of the Same Operating System

Starting with AIX 5.1, different versions of AIX can exist within different LPARs in the same system. This enables a single system to have different versions of the operating system installed to accommodate multiple application requirements. Furthermore, an LPAR can be created to test applications under new versions of the operating system *prior* to upgrading the production environments. Instead of having a separate server for this function, a minimum set of resources can be temporarily used to create a new LPAR where the tests are performed. When the partition is no longer needed, its resources can be incorporated back into the other LPARs.

Chapter 3. Logical Partition Scenarios and Recommendations

This chapter provides an overview of the AIX installation process and various installation scenarios you can perform. Because the managed system may be the first AIX system in your environment (or the first AIX 5.1 system in an AIX 4.3 environment), this information and accompanying recommendations will help guide you on decisions about installation, maintenance, and system backup.

Overview of AIX Installation Process

Due to the physical configuration of a managed system, use of the Network Installation Management (NIM) environment to install AIX is recommended. The following table compares how different forms of media proceed through the AIX installation process:

Table 4. AIX Installation Process Comparison


Steps	CD-ROM Product Media	NIM	mksysb on CD-R or DVD-RAM	mksysb on tape
Booting	Boot image is stored and retrieved from CD.	Boot image is stored on NIM server. Boot image is retrieved from network by firmware.	Boot image is stored and retrieved from CD-R or DVD.	Boot image is stored and retrieved from the first image on tape.
Making BOS Installation Choices	Manually step through the BOS menu selections for disks, kernel, language, and so on.	Perform non-prompted installation using a bosinst.data file to answer the BOS menu questions.	Manually proceed through the BOS menu selections for disks, kernel, language, and so on.	Manually proceed through the BOS menu selections for disks, kernel, language, and so on.
Executing Commands During Installation	CD-filesystem is mounted and commands are executed.	SPOT file system is NFS mounted and commands are run from the SPOT.	CD-filesystem is mounted and commands are executed.	Command files are retrieved from second image on tape to RAM-filesystem in memory.
Installing Product Images	Installation images stored on CD in a filesystem.	Installation images are stored in LPP_Source, which is NFS mounted during installation.	Backup image is stored on CD-R or DVD-RAM in a filesystem.	Backup image is stored and retrieved from fourth image on tape.
Rebooting System and Logging into System	Use Configuration Assistant (or Installation Assistant) to accept license agreements, set paging space, and so on.	No Configuration Assistant (or Installation Assistant). Boot to login prompt.	No Configuration Assistant (or Installation Assistant). Boot to login prompt.	No Configuration Assistant (or Installation Assistant). Boot to login prompt.

Introduction to Network Installation Management


This section provides an introduction to the NIM environment and the operations you can perform to manage the installation of the Base Operating System (BOS) and optional software on one or more machines. NIM gives you the ability to install and maintain not only the AIX operating system, but also any additional software and fixes that may be applied over time. NIM also allows you to customize the configuration of machines both during and after installation. NIM eliminates the need for access to physical media, such as tapes and CD-ROMs, because the media is a NIM resource on a server. System backups can be created with NIM, and stored on any server in the NIM environment, including the NIM master. Use NIM to restore a system backup to the same partition or to another partition. Before you begin configuring the NIM environment, you should already have the following:

- NFS and TCP/IP installed
- TCP/IP configured correctly
- Name resolution configured

For any installation procedure, you need a software source to install from, such as the AIX product CD-ROM. The AIX product CD-ROM contains boot images used to boot the system from the CD-ROM, installation images, and the installation commands used to install the installation images, as shown in the following illustration:




In the NIM environment, the software source is separated into two NIM resources, the LPP_Source and the SPOT. The LPP_Source is a directory on your NIM server. When the LPP_Source is created, installation images are copied from the product CD-ROM to the LPP_Source directory, as shown in the following illustration:



The product CD-ROM also contains boot images that enable the system to boot from the CD-ROM and installation commands that are used to install the installation images. This equivalent NIM resource is called the SPOT (Shared Product Object Tree). The SPOT is a directory that contains the installation commands that are used to install the installation images from the LPP_Source onto a system. The SPOT

is also used to build the necessary boot images to boot a client system. Separate boot images exist for each type of adapter (Ethernet, token ring, and so on).



In AIX 5.1, scripts are available that configure the NIM environment for you and create the resources necessary to perform a **mksysb** installation. The **nim_master_setup** script creates an LPP_Source and SPOT resource for you and defines the resources in the NIM environment. The **nim_master_setup** script will also copy the update images from your update CD to the LPP_Source and then install the update images into the SPOT resource.

In addition to the LPP_Source and SPOT resources, several NIM resources can help customize the BOS installation process and basic network configuration. The following table shows all the NIM resources that are created with the **nim_master_setup** script:

*Table 5. NIM resources created by **nim_master_setup** script*

NIM Resource	Name Given	Description
lpp_source*	510lpp_res	Directory containing installation images.
spot*	510spot_res	Commands used during installation. The network boot images are built from the SPOT.
mksysb	generic_sysb	System backup image
bosinst_data	bid_tty_ow bid_lft_ow	Answers questions asked during the BOS installation, which allows for a non-prompted installation.
resolv_conf	resolv_res	Provides the domain name and name server information.
res_group	basic_res_grp	Used by the nim_clients_setup script to allocate the bosinst_data, mksysb, lpp_source, spot, and resolv_conf to install the client partitions.

* Required resource for installation

Each partition you install will be defined in the NIM environment as a standalone system resource, also referred to as a NIM client. The **nim_clients_setup** script allows you to define the partitions as NIM clients and initiates a BOS installation on the NIM clients.

Installation Scenarios

This section contains several scenarios for installing AIX.

Updating an Existing AIX 5.1 System

In this scenario, you are adding a managed system to an existing environment of systems running AIX 5.1. You would like to replace several of the existing systems with partitions. You decide that you want to use a system backup from an existing system and use its AIX 5.1 image to populate several of the partitions.

In your existing environment, you have an AIX 5.1 system with a graphics adapter and approximately 1.5 Gb extra hard disk space. You decide to configure this system as a NIM master and use NIM to install the system backup to the partitions on the managed system. If you already have a NIM master set up, you can still use this procedure to create the AIX 5.1 NIM resources. Do the following:

1. Before you make the system backup, update the system to the recommended maintenance package level. Insert the latest update CD of AIX 5L for POWER Version 5.1 Volume 1 into the CD device of the system. Run the following command:

```
geninstall -d/dev/cd0 bos.rte.install
```

This will update the installation commands to the latest maintenance package level.

2. Run the **install_all_updates** script, as follows:

```
install_all_updates -d /dev/cd0
```

The **install_all_updates** script will first check if your system is at the latest known recommended maintenance level.

If your system is not at the latest known recommended maintenance level, then the **install_all_updates** script updates the system to the latest maintenance level of AIX.

Note: The output from the **install_all_updates** script is also saved in the **/var/adm/ras/install_all_updates.log** log file.

3. After the update is complete, the system will instruct you to reboot the system. Reboot the system by using the **shutdown** command as follows:

```
shutdown -Fr
```
4. Create a system backup and configure the system or another partition-ready system as a NIM master. You will use the NIM master to install the system backup to the partitions. Refer to “Step-by-Step: Using a Separate AIX System as a NIM Master to Use NIM to Install Each Partition” on page 16 for the procedure.

First AIX System in Your Environment

In this scenario, the managed system is the first AIX system in your environment, and you do not have another system with a graphics adapter available. In this case, you must use the HMC as both your software and hardware console.

If you do not have a great deal of experience using AIX, use the procedure described in “Step-by-Step: Configuring an Initial Partition as a NIM Master to Use NIM to Install the Remaining Partitions” on page 23. This procedure will create a NIM master on one of the partitions and use its system image to install the other partitions.

NIM enables you to install and customize your logically partitioned environment. Using the NIM environment enables you to perform future installation and maintenance tasks more efficiently.

Migrating to AIX 5.1 and Configuring Partition Support

In this scenario, you are adding a managed system to an existing environment of systems running AIX 4.3 or earlier. The managed system is the first system in your environment that requires AIX 5.1. If you have a system available to use as a NIM master, or you already have a NIM master, perform the following steps:

1. Migrate the system to AIX 5.1. Refer to “Step-by-Step: Migrating a System to the AIX 5.1 Partition-Ready State” on page 36 for the procedure.
2. Configure the system to be a NIM master. You will use the NIM master to install the system backup on your partitions. If you do not have an available system to use as a AIX 5.1 NIM master, refer to the “Step-by-Step: Configuring an Initial Partition as a NIM Master to Use NIM to Install the Remaining Partitions” on page 23.

Installing a Partition Using Alternate Disk Installation

You can clone an existing disk image to another disk or disks without using NIM. You may want to do this if your network is not fully set up, or if you are not sure about your network configuration. However, you may choose to use NIM at a later time.

You can use the `alt_disk_install` command to clone a system image to another disk, but you must use the `-O` option to remove references in the ODM and device (`/dev`) entries to the existing system. The cloned disk can now be booted as if it were a new system.

An example of this scenario is as follows:

1. Boot the managed system as a Full System Partition so you have access to all the disks in the managed system.
2. Configure the system and install the necessary applications.
3. Run the `alt_disk_install` command to begin cloning the `rootvg` on `hdisk0` to `hdisk1`, as follows:

```
# /usr/sbin/alt_disk_install -O -B -C hdisk1
```

The cloned disk (`hdisk1`) will be named `altinst_rootvg` by default.

4. Rename the cloned disk (`hdisk1`) to `alt1`, so you can repeat the operation with another disk.

```
# /usr/sbin/alt_disk_install -V alt1 hdisk1
```
5. Run `alt_disk_install` again to clone to another disk and rename the cloned disk, as follows:

```
# /usr/sbin/alt_disk_install -O -B -C hdisk2  
# /usr/sbin/alt_disk_install -V alt2 hdisk2
```
6. Repeat this procedure for all of the disks that you want to clone.
7. Use the HMC to partition the managed system with the newly cloned disks. Each partition you create will now have a `rootvg` with a boot image.
8. Boot the partition into SMS mode. Use the SMS **MultiBoot** menu to configure the first boot device to be the newly installed disk. Exit the SMS menus and boot up the system.

For a full description of alternate disk installation, see the `alt_disk_install` man page and the *AIX 5L Version 5.1 Installation Guide*.

Adding Your Managed System to an RS/6000 SP Environment

For information about planning, installing, and configuring on RS/6000 SP systems, refer to the following Web site:

http://www.rs6000.ibm.com/resource/aix_resource/sp_books/pssp/index.html

Advanced Installation Options

There are several other scenarios to install your partitions by using some AIX advanced functions. These procedures are documented in the `/usr/lpp/bos/README.PARTITION_INSTALL` file.

Some scenarios covered are:

- Preparing an existing root volume group (**rootvg**) to move to a managed system.
- Using the **devreset** command to rebuild the device ODM database and reset all devices to default configurations.

Chapter 4. Installing AIX in a Partitioned Environment

This chapter contains step-by-step procedures to install the AIX operating system in a partitioned environment. For more information on concepts and the considerations involved when performing a base operating system installation of AIX, refer to the *AIX 5L Version 5.1 Installation Guide*. For more information on concepts and the requirements involved when using the Network Installation Management (NIM) environment to install and maintain AIX, refer to the *AIX 5L Version 5.1 Network Installation Management Guide and Reference*.

For step-by-step instructions on how to create a partition and allocate I/O resources to a partition, see the *IBM Hardware Management Console for pSeries Operations Guide*. To help you keep track of the LPAR environment system resources, see the LPAR Planning and the LPAR Resource Tracking Worksheets in the *IBM Hardware Management Console for pSeries Operations Guide*.

Note: For the installation method that you choose, ensure that you follow the sequence of steps as shown. Within each procedure, you must use AIX to complete some installation steps, while other steps are completed using the HMC interface.

Installation Procedure	Considerations
“Step-by-Step: Using a Separate AIX System as a NIM Master to Use NIM to Install Each Partition” on page 16	<ul style="list-style-type: none"> You need not dedicate an LPAR as the NIM master. NIM environment offers the most flexibility and customization options for installation and management. NIM environment allows for multiple installations at the same time. The nim_master_setup and nim_clients_setup scripts provide a way to set up the NIM environment. Requires an available AIX 5.1 system that can be used as the NIM master.
“Step-by-Step: Configuring an Initial Partition as a NIM Master to Use NIM to Install the Remaining Partitions” on page 23	<ul style="list-style-type: none"> NIM environment offers the most flexibility and customization options for installation and management. NIM environment allows for multiple installations at the same time. The nim_master_setup and nim_clients_setup scripts provide a way to set up the NIM environment. Requires one LPAR with approximately 1.5 GB of disk space dedicated as the NIM Master partition.
“Step-by-Step: Using the CD Device to Manually Install a Partition” on page 30	<ul style="list-style-type: none"> You need not set up the NIM environment. Installing AIX from CD can be time-consuming. No convenient way to do systems management functions. More work required on Hardware Management Console (HMC) to activate and deactivate LPARs.
“Step-by-Step: Migrating a System to the AIX 5.1 Partition-Ready State” on page 36	<ul style="list-style-type: none"> Some applications on the pre-migrated operating system may not be certified or compatible with AIX 5.1. See http://www-1.ibm.com/servers/aix/products/ibmsw/list/ for currently available applications.
“Step-by-Step: Updating a Partition to the AIX 5.1 Partition-Ready State” on page 39	The install_all_updates script provides a one-step method to update an AIX 5.1 system to the latest AIX 5.1 maintenance level.
“Step-by-Step: Updating an Existing NIM Environment to the Latest AIX 5.1 Maintenance Level” on page 40	The nim_update_all script provides a one-step method to update an existing NIM environment and its resources created with the nim_master_setup script to the latest AIX 5.1 maintenance level.

Step-by-Step: Using a Separate AIX System as a NIM Master to Use NIM to Install Each Partition

In this procedure, you will use a separate system running AIX 5.1 as a NIM master and server, to use NIM to install your logical partitions. As with any NIM environment, you must make sure your network environment is already defined and working correctly.

After the correct level of the AIX operating system has been installed on this separate system, as the root user, you will set up the NIM environment using the **nim_master_setup** script. The **nim_master_setup** script automatically installs the **bos.sysmgt.nim.master** fileset from your media, configures the NIM master, and creates a generic system backup that will be used to install the partitions, as well as the SPOT and LPP_Source resources.

Note: The **nim_master_setup** script uses the **rootvg** volume group and creates an **/export/nim** file system, by default. You can change these defaults using the **volume_group** and **file_system** options. The **nim_master_setup** script also allows you to optionally not create a generic system backup, if you plan to use a **mksysb** image from another system to install your partitions.

You will then define your clients using SMIT or using the NIM **clients.def** file, then use the **nim_clients_setup** script to allocate the installation resources, and initiate a NIM BOS installation on the clients. Then using the HMC, you will activate the partitions and configure them to boot off the network.

Prerequisites

Before you begin this procedure, you should have used the HMC to create partitions and partition profiles for each partition that you want to install. Be sure each partition has a network adapter assigned. Set the boot mode for each partition to be SMS mode. After you have successfully created the partitions and partition profiles, leave the partitions in the *Ready* state. Do *not* activate the partitions yet.

1. Configure NIM Master and Initiate Installation of Partitions (Perform These Steps in the AIX Environment)

___ Step 1. Run the **oslevel** command as follows:

```
oslevel -r
```

Output similar to the following displays:

```
5100-02
```

The **oslevel** command reports the maintenance level of the operating system using a subset of all filesets installed on your system. If the output from the **oslevel** command does not show the expected maintenance level, see “Step-by-Step: Migrating a System to the AIX 5.1 Partition-Ready State” on page 36 for information about migrating the AIX operating system to the correct maintenance level, or “Step-by-Step: Updating a Partition to the AIX 5.1 Partition-Ready State” on page 39 for information about updating the AIX operating system to the correct maintenance level.

___ Step 2. Verify network configuration by running the following commands:

```
smitty mktcpip
```

Select the Network Interface and press Enter.

Confirm or enter your host name, IP address, name server, domain name, default gateway, as well as ring speed or cable type. Press Enter.

You can also test the network status by using the following **netstat** command options:

```
netstat -C
```


The **-C** flag shows the routing table information. Check to make sure your gateway information is correct.

netstat -D

The **-D** flag shows the number of packets received, transmitted, and dropped in the communications subsystem. Check to make sure the network device is sending and receiving packet information.

___ Step 3. Insert the latest recommended maintenance level of **AIX 5L for POWER Version 5.1** Volume 1 in the CD device.

Run the **nim_master_setup** command as follows:

nim_master_setup

This command configures the NIM environment on the AIX system by installing the **bos.sysmgmt.nim.master** fileset, configuring the NIM environment, and creating the boot, nim_script, resolv_conf, bosinst_data, LPP_Source, and SPOT resources needed for a BOS installation. The **-B** flag is used to prevent creating the mksysb resource, if you plan to use a mksysb image from another system. The **nim_master_setup** script uses the **/dev/cd0** device as the default device. You can specify an alternate location using the **-a device=full_path_name** option.

The **nim_master_setup** script uses the **rootvg** volume group and creates an **/export/nim** file system, by default. You can change these defaults by using the **volume_group** and **file_system** options.

Output similar to the following displays:

```
##### NIM master setup #####
#
# During script execution, lpp_source and spot resource creation times      #
# may vary. To view the install log at any time during nim_master_setup,    #
# run the command: tail -f /var/adm/ras/nim.setup in a separate screen.     #
#                                                                              #
#####
```

```
Creating image.data file....done
Device location is /dev/cd0
Resources will be defined on volume group rootvg
Resources will exist in filesystem /export/nim
Checking for backup software....already installed
Checking /tmp space requirement....done
Installing NIM master fileset....
...
Defining NIM master...
0513-071 The nimesis Subsystem has been added.
0513-071 The nimd Subsystem has been added.
0513-059 The nimesis Subsystem has been started. Subsystem PID is 16294.
Located volume group rootvg.
Creating /export/nim filesystem....done
Creating /tftpboot filesystem....done
Checking /export/nim space requirement....done
Creating list of files to back up.....
Backing up 24588 files.....
6027 of 24588 files (24%).....
14681 of 24588 files (59%).....
23328 of 24588 files (94%).
24588 of 24588 files (100%)
0512-038 mksysb: Backup Completed Successfully.
Creating mksysb resource generic_sysb....done
Creating resolv_conf resource resolv_res....done
Creating bosinst_data resource (tty) bid_tty_ow....done
Creating bosinst_data resource (lft) bid_lft_ow....done
Checking /export/nim space requirement....done
Creating lpp_source resource 510lpp_res....done
```

```

Checking /export/nim space requirement....done
Checking /tftpboot space requirement....done
Creating spot resource 510spot_res....done
Creating resource group basic_res_grp....done

```

The following resources now exist:

```

boot          resources      boot
nim_script    resources      nim_script
generic_sysb  resources      mksysb
resolv_res    resources      resolv_conf
bid_tty_ow    resources      bosinst_data
bid_lft_ow    resources      bosinst_data
510lpp_res    resources      lpp_source
510spot_res   resources      spot

```

NIM master setup is complete - enjoy!

Note: The output from the **nim_master_setup** script is stored in the **/var/adm/ras/nim.setup** log file.

- ___ Step 4. If you are adding new client machines that cannot be resolved on the name server, edit the **/etc/hosts** file to add the IP addresses and client host names.
- ___ Step 5. There are two ways to define the client systems and initiate the BOS Installation. The first method uses the SMIT interface to define the clients and then uses the **nim_clients_setup** script to initiate the installation. The second method allows you to manually edit the **client.defs** file and then use the **nim_clients_setup** script to define the clients with this file and then initiate the installation. This section describes both methods:

-

Use SMIT and the **nim_clients_setup** script, as follow:

- a. Run the **smitty nim_mkclient** fast path and the **nim_clients_setup** script to define the client partitions in the NIM environment.

```
smitty nim_mkclient
```

Select **Add a NIM Client**

Enter a host name and press Enter.

Define a Machine

Type or select a value for the entry field.
Press Enter AFTER making all desired changes.

* Host Name of Machine
(Primary Network Install Interface)

[Entry Fields]
[1par1]

If a menu prompts you for the Type of Network Attached to Primary Network Install Interface, select the network adapter from the list and press Enter.

In the Define a Machine menu, supply the necessary information by typing in the entry fields or using the F4 key to open a selection menu. Verify all information is correct, especially the Hardware Platform Type (chrp), Kernel Type (mp), and Network Type. Press Enter when you are finished.

```

Define a Machine

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

[TOP]
* NIM Machine Name          [Entry Fields] [lpar1]
* Machine Type              [standalone]      +
* Hardware Platform Type   [chrp]            +
  Kernel to use for Network Boot [mp]            +
  Primary Network Install Interface
* Cable Type                bnc                +
* NIM Network               [ent-Network1]
* Network Type              ent
* Ethernet Type             Standard          +
* Subnetmask                []
* Default Gateway Used by Machine []
* Default Gateway Used by Master []
* Host Name                 lpar1
  Network Adapter Hardware Address [0]

```

- b. Repeat for each client partition. Use the F3 key to return to the previous menu, and change the information for each client.
- c. Run the **nim_clients_setup** script as follows:

```
nim_clients_setup
```

The **nim_clients_setup** command creates a NIM machine group with the clients you just defined using the SMIT interface, then allocates the LPP_Source, SPOT, mksysb, bosinst.data, and resolv.conf resources, and finally initiates a NIM mksysb installation. The NIM mksysb installation uses the **generic_sysb** resource that was created with the **nim_master_setup** script. If you want to use another mksysb image, use the **-m mksysb_path** option, and the script defines and uses it to install the partitions. The path must be local to the master.

- Use a text editor to manually edit the **client.defs** file and use the **nim_clients_setup** script, as follows:
 - a. Use the **vi** editor to customize the **/export/nim/client.defs** file as follows:

```
vi /export/nim/client.defs
```

Edit the **client.defs** file according to your environment. For more information, see the instructions and examples in the **client.defs** file. When you are finished editing the **client.defs** file, save it and exit the vi editor.

- b. Run the **nim_clients_setup** script to define the client partitions in the NIM environment as follows:

```
nim_clients_setup -c
```

The **-c** option specifies using the **client.defs** for your client definitions. The **nim_clients_setup** command creates a NIM machine group with all the resources created from the **nim_master_setup** script and initiates a NIM mksysb installation. If you want to use another mksysb image, use the **-m mksysb_path** option, and the script defines and uses it to install the partitions. The path must be local to the master.

2. Activate and Install Partitions (Perform These Steps in the HMC Interface)

- ___ Step 1. To activate the partitions, do the following:
 - a. Select the partition (or partition profile) you want to activate.
 - b. Right-click on the partition (or partition profile) to open the menu.

- c. Select **Activate**. The Activate Partition menu opens with a selection of partition profiles. Select a partition profile that is set to boot to the SMS menus.
- d. Select **Open terminal** at the bottom of the menu to open a virtual terminal (vterm) window.
- e. Select **OK**. A vterm window opens for each partition. After several seconds, the System Management Services (SMS) menu opens in the vterm window.

___ Step 2. In the SMS menu on the vterm window, do the following:

- a. Press the 6 key to select **6 Multiboot**.

```
Version RHxxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Utilities

1 Password Utilities NOT available in LPAR mode
2 Display Error Log
3 Remote Initial Program Load Setup
4 SCSI Utilities
5 Select Console NOT available in LPAR mode
6 MultiBoot
7 Select Language
8 OK Prompt

====> 6
```

[X=Exit]

- b. Press the 4 key to select **4 Select Boot device**.
- c. Press the 3 key to select **3 Configure 1st boot device**.

```
Version RHxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Select Boot Devices

1 Display Current Settings
2 Restore Default Settings
3 Configure 1st Boot Device
4 Configure 2nd Boot Device
5 Configure 3rd Boot Device
6 Configure 4th Boot Device
7 Configure 5th Boot Device

====> 3
```

[X=Exit]

- d. Select the network adapter from the list of available devices.
- e. Press the x key until you return to the Utilities menu.
- f. Press the 3 key to select **3 Remote Initial Program Load Setup**.

```
Version RHxxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Utilities

1 Password Utilities NOT available in LPAR mode
2 Display Error Log
3 Remote Initial Program Load Setup
4 SCSI Utilities
5 Select Console NOT available in LPAR mode
6 MultiBoot
7 Select Language
8 OK Prompt

                                     [X=Exit]

====> 3
```

- g. Press the 1 key to select **1. IP Parameters**.
- h. Type the appropriate information for Client IP Address, Server IP Address, Gateway IP Address, and Subnet Mask. Press the x key to exit to the Network Parameters menu.

```
Version RHxxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
IP Parameters

1. Client IP Address                [000.000.000.000]
2. Server IP Address                [000.000.000.000]
3. Gateway IP Address               [000.000.000.000]
4. Subnet Mask                      [255.255.255.000]

                                     [X=Exit]

====>
```

- i. Press the 2 key to select **2 Adapter Parameters**.
- j. Select the network device you want to use and press Enter. If a menu prompts for further configuration of the network device, select the appropriate settings. When you are finished, press Enter to exit to the Network Properties menu.
- k. Press the x key to exit to the previous menu.
- l. Press the 3 key to select **3 PING Test**.
- m. Select the network adapter for the ping test and press Enter.
- n. If another menu displays the network adapter configuration information, press the x key to exit to the previous menu.
- o. Press the x key to exit to the previous menu.
- p. Press the e key to execute the ping operation.

```

Version RHxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Ping IP Address

1. Client IP Address           [000.000.000.000]
2. Server IP Address          [000.000.000.000]
3. Gateway IP Address         [000.000.000.000]
4. Subnet Mask                 [255.255.255.000]

-----
|E=Execute|                    |X=Exit|
-----
===> e

```

- If the ping operation does not return successfully, return to the **1. IP Parameters** menu selection to make sure all information is correctly entered. Also, check the **2 Adapter Parameters** to make sure the network adapter configuration is correct according to your network. You may also want to make sure the network adapter is functioning correctly.
- If the ping operation returns successfully, proceed with the network boot. Press the x key until you exit the SMS menus and begin the network boot.

3. Log in to Your Partition (Perform this step in the AIX environment)

When the installation has completed and the system has rebooted, the vterm window displays a login prompt.

At this point, you may want to perform several common system-administration procedures. The following table lists where to find information about performing these procedures.

Table 6. Common System Administration Procedures

Procedure	Location
Partition Backup and Storage Management	Chapter 5, "System Backup, Dump, and Storage Management" on page 43
Remote Systems Management	Chapter 6, "Remote Management" on page 53
User and Group Management	<i>AIX 5L Version 5.1 System Management Guide: Operating System and Devices</i>
Software Installation	<i>AIX 5L Version 5.1 Installation Guide</i>
Performance Management	<i>AIX 5L Version 5.1 Performance Management Guide</i>
Printer Configuration	<i>AIX 5L Version 5.1 Guide to Printers and Printing</i>

Step-by-Step: Configuring an Initial Partition as a NIM Master to Use NIM to Install the Remaining Partitions

In this procedure, you will set up an initial logical partition as a NIM master and server. This procedure refers to this initial logical partition as the **Master_LPAR**. It is assumed that AIX is already installed and configured for network communication in the Master_LPAR. Make sure your network environment is already defined and working correctly before configuring the NIM environment.

After you verify the correct level of the AIX operating system has been installed on the Master_LPAR, as the root user, you will set up the NIM environment using the **nim_master_setup** script. The **nim_master_setup** script automatically installs the **bos.sysmgt.nim.master** fileset, configures the NIM master, and creates the required resources for installation, including a mksysb system backup.

Note: The **nim_master_setup** script uses the **rootvg** volume group and creates an **/export/nim** file system, by default. You can change these defaults using the **volume_group** and **file_system** options. The **nim_master_setup** script also allows you to optionally not create a generic system backup, if you plan to use a mksysb image from another system.

You will then use the **nim_clients_setup** script to define your NIM clients, allocate the installation resources, and initiate a NIM BOS installation on the clients. Then using the HMC, you will activate the client partitions and configure them to boot off the network.

Prerequisites

Before you begin this procedure, you should have already performed the following tasks:

- Use the HMC to create the Master_LPAR logical partition and partition profile. Be sure the Master_LPAR partition has a network adapter, enough hard-disk space for the NIM resources, and an assigned CD device. Set the boot mode for the Master_LPAR partition to be Normal mode. After you have successfully created the partition and partition profile, leave the partition in the *Ready* state. Do *not* activate the partition yet.
- Use the HMC to create logical partitions and partition profiles for each NIM client. Be sure each LPAR has a network adapter assigned. Set the boot mode for each partition to be SMS mode. After you have successfully created the partitions and partition profiles, leave the partitions in the *Ready* state. Do *not* activate the partitions yet.
- Configure AIX for network communication on the Master_LPAR. If AIX is not currently installed on any of the disks in the system, then refer to “Step-by-Step: Using the CD Device to Manually Install a Partition” on page 30 for the procedure.

1. Activate the Master_LPAR (Perform this Step in the HMC Interface)

After you have successfully created the Master_LPAR, it is in a *READY* state.

Use the HMC to activate the Master_LPAR partition, as follows:

- ___ Step 1. To activate the Master_LPAR, do the following:
 - a. Select the Master_LPAR partition.
 - b. Right-click on the partition to open the menu.
 - c. Select **Activate**. The Activate Partition menu opens with a selection of partition profiles. Be sure the correct partition profile is highlighted.
 - d. Select **Open terminal** at the bottom of the menu to open a virtual terminal (vterm) window.
 - e. Select **OK**. A virtual terminal (vterm) window opens for the partition. After several seconds, the login prompt displays in the vterm window.

2. Configure NIM Master and Initiate Installation of Partitions (Perform These Steps in the AIX Environment)

___ Step 1. Run the **oslevel** command as follows:

```
oslevel -r
```

Output similar to the following displays:

```
5100-02
```

The **oslevel** command reports the maintenance level of the operating system using a subset of all filesets installed on your system. If the output from the **oslevel** command does not show the expected maintenance level, see “Step-by-Step: Migrating a System to the AIX 5.1 Partition-Ready State” on page 36 for information about migrating the AIX operating system to the correct maintenance level, or “Step-by-Step: Updating a Partition to the AIX 5.1 Partition-Ready State” on page 39 for information about updating the AIX operating system to the correct maintenance level.

___ Step 2. Verify network configuration by running the following commands:

```
smitty mktcpip
```

Select the Network Interface and press Enter.

Confirm or enter your host name, IP address, name server, domain name, default gateway, as well as ring speed or cable type. Press Enter.

You can also test the network status by using the following **netstat** command options:

```
netstat -C
```

The **-C** flag shows the routing table information. Check to make sure your gateway information is correct.

```
netstat -D
```

The **-D** flag shows the number of packets received, transmitted, and dropped in the communications subsystem. Check to make sure the network device is sending and receiving packet information.

___ Step 3. Insert the latest recommended maintenance level of **AIX 5L for POWER Version 5.1** Volume 1 in the CD device.

Run the **nim_master_setup** command as follows:

```
nim_master_setup
```

This command configures the NIM environment on the AIX system by installing the **bos.sysmgmt.nim.master** fileset, configuring the NIM environment, and creating the boot, **nim_script**, **resolv_conf**, **bosinst_data**, **LPP_Source**, and **SPOT** resources needed for a BOS installation. The **-B** flag is used to prevent creating the **mksysb** resource, if you plan to use a **mksysb** image from another system. The **nim_master_setup** script uses the **/dev/cd0** device as the default device. You can specify an alternate location using the **-a device=full_path_name** option.

The **nim_master_setup** script uses the **rootvg** volume group and creates an **/export/nim** file system, by default. You can change these defaults by using the **volume_group** and **file_system** options.

Output similar to the following displays:

```
##### NIM master setup #####  
#  
# During script execution, lpp_source and spot resource creation times #  
# may vary. To view the install log at any time during nim_master_setup, #  
# run the command: tail -f /var/adm/ras/nim.setup in a separate screen. #
```



```
#
#####
```

```
Creating image.data file....done
Device location is /dev/cd0
Resources will be defined on volume group rootvg
Resources will exist in filesystem /export/nim
Checking for backup software....already installed
Checking /tmp space requirement....done
Installing NIM master fileset....
...
Defining NIM master...
0513-071 The nimesis Subsystem has been added.
0513-071 The nimd Subsystem has been added.
0513-059 The nimesis Subsystem has been started. Subsystem PID is 16294.
Located volume group rootvg.
Creating /export/nim filesystem....done
Creating /tftpboot filesystem....done
Checking /export/nim space requirement....done
Creating list of files to back up.....
Backing up 24588 files.....
6027 of 24588 files (24%).....
14681 of 24588 files (59%).....
23328 of 24588 files (94%).
24588 of 24588 files (100%)
0512-038 mksysb: Backup Completed Successfully.
Creating mksysb resource generic_sysb....done
Creating resolv_conf resource resolv_res....done
Creating bosinst_data resource (tty) bid_tty_ow....done
Creating bosinst_data resource (lft) bid_lft_ow....done
Checking /export/nim space requirement....done
Creating lpp_source resource 510lpp_res....done
Checking /export/nim space requirement....done
Checking /tftpboot space requirement....done
Creating spot resource 510spot_res....done
Creating resource group basic_res_grp....done
```

The following resources now exist:

boot	resources	boot
nim_script	resources	nim_script
generic_sysb	resources	mksysb
resolv_res	resources	resolv_conf
bid_tty_ow	resources	bosinst_data
bid_lft_ow	resources	bosinst_data
510lpp_res	resources	lpp_source
510spot_res	resources	spot

NIM master setup is complete - enjoy!

Note: The output from the **nim_master_setup** script is stored in the **/var/adm/ras/nim.setup** log file.

- ___ Step 4. If you are adding new client machines that cannot be resolved on the name server, edit the **/etc/hosts** file to add the IP addresses and client host names.
- ___ Step 5. There are two ways to define the client systems and initiate the BOS Installation. The first method uses the SMIT interface to define the clients and then uses the **nim_clients_setup** script to initiate the installation. The second method allows you to manually edit the **client.defs** file and then use the **nim_clients_setup** script to define the clients with this file and then initiate the installation. This section describes both methods:

-

Use SMIT and the **nim_clients_setup** script, as follow:

- a. Run the **smitty nim_mkclient** fast path and the **nim_clients_setup** script to define the client partitions in the NIM environment.

```
smitty nim_mkclient
```

Select **Add a NIM Client**

Enter a host name and press Enter.

Define a Machine

Type or select a value for the entry field.
Press Enter AFTER making all desired changes.

	[Entry Fields]
* Host Name of Machine (Primary Network Install Interface)	[lpar1]

If a menu prompts you for the Type of Network Attached to Primary Network Install Interface, select the network adapter from the list and press Enter.

In the Define a Machine menu, supply the necessary information by typing in the entry fields or using the F4 key to open a selection menu. Verify all information is correct, especially the Hardware Platform Type (chrp), Kernel Type (mp), and Network Type. Press Enter when you are finished.

Define a Machine

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

[TOP]	[Entry Fields]	
* NIM Machine Name	[lpar1]	
* Machine Type	[standalone]	+
* Hardware Platform Type	[chrp]	+
Kernel to use for Network Boot	[mp]	+
Primary Network Install Interface		
* Cable Type	bnc	+
* NIM Network	[ent-Network1]	
* Network Type	ent	
* Ethernet Type	Standard	+
* Subnetmask	[]	
* Default Gateway Used by Machine	[]	
* Default Gateway Used by Master	[]	
* Host Name	lpar1	
Network Adapter Hardware Address	[0]	

- b. Repeat for each client partition. Use the F3 key to return to the previous menu, and change the information for each client.
- c. Run the **nim_clients_setup** script as follows:

```
nim_clients_setup
```

The **nim_clients_setup** command creates a NIM machine group with the clients you just defined using the SMIT interface, then allocates the LPP_Source, SPOT, mksysb, bosinst.data, and resolv.conf resources, and finally initiates a NIM mksysb installation. The NIM mksysb installation uses the **generic_sysb** resource that was created with the **nim_master_setup** script. If you want to use another mksysb image, use the **-m mksysb_path** option, and the script defines and uses it to install the partitions. The path must be local to the master.

- Use a text editor to manually edit the **client.defs** file and use the **nim_clients_setup** script, as follows:
 - a. Use the **vi** editor to customize the **/export/nim/client.defs** file as follows:

```
vi /export/nim/client.defs
```

Edit the **client.defs** file according to your environment. For more information, see the instructions and examples in the **client.defs** file. When you are finished editing the **client.defs** file, save it and exit the vi editor.

- b. Run the **nim_clients_setup** script to define the client partitions in the NIM environment as follows:

```
nim_clients_setup -c
```

The **-c** option specifies using the **client.defs** for your client definitions. The **nim_clients_setup** command creates a NIM machine group with all the resources created from the **nim_master_setup** script and initiates a NIM mkysyb installation. If you want to use another mkysyb image, use the **-m mkysyb_path** option, and the script defines and uses it to install the partitions. The path must be local to the master.

3. Activate and Install Partitions (Perform these steps in the HMC Interface)

___ Step 1. To activate the partitions, do the following:

- a. Select the partition (or partition profile) you want to activate.
- b. Right-click on the partition (or partition profile) to open the menu.
- c. Select **Activate**. The Activate Partition menu opens with a selection of partition profiles. Select a partition profile that is set to boot to the SMS menus.
- d. Select **Open terminal** at the bottom of the menu to open a virtual terminal (vterm) window.
- e. Select **OK**. A vterm window opens for each partition. After several seconds, the System Management Services (SMS) menu opens in the vterm window.

___ Step 2. In the SMS menu on the vterm window, do the following:

- a. Press the 6 key to select **6 MultiBoot**.

```
Version RHxxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
```

Utilities

```
1 Password Utilities NOT available in LPAR mode
2 Display Error Log
3 Remote Initial Program Load Setup
4 SCSI Utilities
5 Select Console NOT available in LPAR mode
6 MultiBoot
7 Select Language
8 OK Prompt
```

[X=Exit]

```
==> 6
```

- b. Press the 4 key to select **4 Select Boot device**.
- c. Press the 3 key to select **3 Configure 1st boot device**.

```

Version RHxxx_xxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Select Boot Devices

1 Display Current Settings
2 Restore Default Settings
3 Configure 1st Boot Device
4 Configure 2nd Boot Device
5 Configure 3rd Boot Device
6 Configure 4th Boot Device
7 Configure 5th Boot Device

                                     [X=Exit]

====> 3

```

- d. Select the network adapter from the list of available devices.
- e. Press the x key until you return to the Utilities menu.
- f. Press the 3 key to select **3 Remote Initial Program Load Setup**.

```

Version RHxxxx_xxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Utilities

1 Password Utilities NOT available in LPAR mode
2 Display Error Log
3 Remote Initial Program Load Setup
4 SCSI Utilities
5 Select Console NOT available in LPAR mode
6 MultiBoot
7 Select Language
8 OK Prompt

                                     [X=Exit]

====> 3

```

- g. Press the 1 key to select **1. IP Parameters**.
- h. Type the appropriate information for Client IP Address, Server IP Address, Gateway IP Address, and Subnet Mask. Press the x key to exit to the Network Parameters menu.

```

Version RHxxxx_xxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
IP Parameters

1. Client IP Address           [000.000.000.000]
2. Server IP Address          [000.000.000.000]
3. Gateway IP Address         [000.000.000.000]
4. Subnet Mask                 [255.255.255.000]

                                     [X=Exit]

====>

```

- i. Press the 2 key to select **2 Adapter Parameters**.
- j. Select the network device you want to use and press Enter. If a menu prompts for further configuration of the network device, select the appropriate settings. When you are finished, press Enter to exit to the Network Properties menu.
- k. Press the x key to exit to the previous menu.

- l. Press the 3 key to select **3 PING Test**.
- m. Select the network adapter for the ping test and press Enter.
- n. If another menu displays the network adapter configuration information, press the x key to exit to the previous menu.
- o. Press the x key to exit to the previous menu.
- p. Press the e key to execute the ping operation.

```

Version RHxxx_xxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Ping IP Address

1. Client IP Address           [000.000.000.000]
2. Server IP Address          [000.000.000.000]
3. Gateway IP Address         [000.000.000.000]
4. Subnet Mask                 [255.255.255.000]

[E=Execute]                    [X=Exit]
===> e

```

- If the ping operation does not return successfully, return to the **1. IP Parameters** menu selection to make sure all information is correctly entered. Also, check the **2 Adapter Parameters** to make sure the network adapter configuration is correct according to your network. You may also want to make sure the network adapter is functioning correctly.
- If the ping operation returns successfully, proceed with the network boot. Press the x key until you exit the SMS menus and begin the network boot.

4. Log in to Your Partition (Perform this step in the AIX environment)

When the installation has completed and the system has rebooted, the vterm window displays a login prompt.

At this point, you may want to perform several common system-administration procedures. The following table lists where to find information about performing these procedures.

Table 7. Common System Administration Procedures

Procedure	Location
Partition Backup and Storage Management	Chapter 5, "System Backup, Dump, and Storage Management" on page 43
Remote Systems Management	Chapter 6, "Remote Management" on page 53
User and Group Management	<i>AIX 5L Version 5.1 System Management Guide: Operating System and Devices</i>
Software Installation	<i>AIX 5L Version 5.1 Installation Guide</i>
Performance Management	<i>AIX 5L Version 5.1 Performance Management Guide</i>
Printer Configuration	<i>AIX 5L Version 5.1 Guide to Printers and Printing</i>

Step-by-Step: Using the CD Device to Manually Install a Partition

In this procedure, you will use the system's built-in CD device to perform a New and Complete Base Operating System Installation on a partition.

Prerequisites

Before you begin this procedure, you should have already used the HMC to create a partition and partition profile for the client. Assign the SCSI bus controller attached to the CD-ROM device, a network adapter, and enough disk space for the AIX operating system to the partition. Set the boot mode for this partition to be SMS mode. After you have successfully created the partition and partition profile, leave the partition in the *Ready* state. For step-by-step instructions on how to create a partition and allocate I/O resources to a partition, refer to the Partition Management chapter of the *IBM IBM Hardware Management Console for pSeries Operations Guide*

1. Activate and Install the Partition (Perform These Steps in the HMC Interface)

- __ Step 1. Activate the partition, as follows:
- Insert the latest recommended maintenance level of **AIX 5L for POWER Version 5.1 Volume 1** into the CD device of the managed system.
 - Right-click on the partition to open the menu.
 - Select **Activate**. The Activate Partition menu opens with a selection of partition profiles. Be sure the correct profile is highlighted.
 - Select **Open terminal** at the bottom of the menu to open a virtual terminal (vterm) window.
 - Select **OK**. A vterm window opens for the partition. After several seconds, the login prompt displays in the vterm window.
- __ Step 2. In the SMS menu on the vterm, do the following:
- Press the 6 key to select **6 Multiboot**.

```
Version RHxxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
-----
Utilities

1 Password Utilities NOT available in partition mode
2 Display Error Log
3 Remote Initial Program Load Setup
4 SCSI Utilities
5 Select Console NOT available in partition mode
6 MultiBoot
7 Select Language
8 OK Prompt

====> 6
```

[X=Exit]

- Press the 4 key to select **4 Select Boot device**.
- Press the 3 key to select **3 Configure 1st boot device**.

```
Version RHxxx_xxxxxx
(c) Copyright IBM Corp. 2001 All rights reserved.
```

```
-----
Select Boot Devices
```

```
1 Display Current Settings
2 Restore Default Settings
3 Configure 1st Boot Device
4 Configure 2nd Boot Device
5 Configure 3rd Boot Device
6 Configure 4th Boot Device
7 Configure 5th Boot Device
```

```
[X=Exit]
```

```
==> 3
```

- d. Select the device number that corresponds to the SCSI CD-ROM device and press Enter. The SCSI CD-ROM device is now the first device in the Current Boot Sequence list.
- e. Press the x key to exit to the previous menu.
- f. Press the 4 key to select **4 Configure 2nd Boot Device**.
- g. Select the device number that corresponds to the hard disk and press Enter.
- h. Press the x key until you exit the SMS Utilities menu. After you exit the last SMS menu, you will be booting off the CD-ROM device.

___ Step 3. Boot from the latest recommended maintenance level of **AIX 5L for POWER Version 5.1** Volume 1, as follows:

- a. Select console and press Enter.
- b. Select language for BOS Installation menus and press Enter to open the Welcome to Base Operating System Installation and Maintenance menu.
- c. Press the 2 key to select **2 Change/Show Installation Settings and Install** in the **>>> Choice [1]:** _ field and press Enter.

```
Welcome to Base Operating System
Installation and Maintenance
```

```
Type the number of your choice and press Enter. Choice is indicated by >>>.
```

```
>>> 1 Start Install Now with Default Settings

    2 Change/Show Installation Settings and Install

    3 Start Maintenance Mode for System Recovery

88 Help ?
99 Previous Menu
>>> Choice [1]: 2
```

___ Step 4. Verify or Change BOS Installation Settings, as follows:

- a. Type 1 in the **Choice** field to select the **System Settings** option.
- b. Type 1 for New and Complete Overwrite in the **Choice** field and press Enter.

Note: The installation methods available depend on whether your disk has a previous version of AIX installed.

- c. When the Change Disk(s) screen displays, you can change the destination disk for the installation. If the default shown is correct, type 0 in the **Choice** field and press Enter. To change the destination disk, do the following:

- 1) Type the number for each disk you choose in the **Choice** field and press Enter. *Do not* press Enter a final time until you have finished selecting all disks. If you must deselect a disk, type its number a second time and press Enter.
 - 2) When you have finished selecting the disks, type 0 in the **Choice** field and press Enter. The Installation and Settings screen displays with the selected disks listed under System Settings.
- d. If needed, change the primary language environment. Use the following steps to change the primary language used by this installation to select the language and cultural convention you want to use.

Note: Changes to the primary language environment do not take effect until after the Base Operating System Installation has completed and your system is rebooted.

- 1) Type 2 in the **Choice** field on the Installation and Settings screen to select the **Primary Language Environment Settings** option.
 - 2) Select the appropriate set of cultural convention, language, and keyboard options. Most of the options are a predefined combination, however, you can define your own combination of options.
 - To choose a predefined Primary Language Environment, type that number in the **Choice** field and press Enter.
 - To configure your own primary language environment, do the following:
 - a) Select **MORE CHOICES**.
 - b) Select **Create Your Own Combination**.
 - c) When the Set Primary Cultural Convention screen displays, type the number in the **Choice** field that corresponds to the cultural convention of your choice and press Enter.
 - d) When the Set Primary Language screen displays, type the number in the **Choice** field that corresponds to your choice for the primary language and press Enter.
 - e) When the Set Keyboard screen displays, type the number in the **Choice** field that corresponds to the keyboard attached to the system and press Enter.
- e. To set Advanced Options, type 3 and press Enter. The available options and their defaults are as follows:
- **1 Installation Package Set (Default)** (ASCII consoles)
 For ASCII systems, you can choose a Minimal or a Default installation. The Default program set might prompt for additional CD volumes during a Base Operating System installation. When prompted for another CD volume, if you do not have additional volumes, type q and press Enter to quit installing additional software. The base operating system installation process will continue.
 Type 1 and press Enter to toggle between choices.
 - **2 Enable Trusted Computing Base**
 The Trusted Computing Base (TCB) is the part of the system that is responsible for enforcing the information security policies of the system. All of the computer's hardware is included in the TCB, but a system administrator is concerned primarily with the software components of the TCB.
 If you install the Trusted Computing Base option, you enable the trusted path, trusted shell, and system integrity checking (**tcbck** command). These features can *only* be enabled during Base Operating System installation.
 The choices are **yes** and **no**. To enable the Trusted Computing Base, type 2 and press Enter. The default is **no**.
 - **3 Enable 64-bit Kernel Support**

To toggle the choice between **no** (the default) and **yes**, type **3** and press Enter. If you choose **no**, the 64-bit kernel is still installed, but it is not linked to the running **/unix**. If you choose **yes**, the 64-bit kernel is installed and begins running when your system reboots. If you choose **yes** and are installing with the New and Complete Overwrite method, the file systems are created with JFS2 (Enhanced Journaled File System), instead of JFS.

Note: If you want the 64-bit kernel to be the running kernel, but you do not want JFS2 file systems, select **no**. After the installation completes, use the following commands to switch to the 64-bit kernel:

```
ln -fs /usr/lib/boot/unix_64 /unix ln -fs /usr/lib/boot/unix_64 \
/usr/lib/boot/unix bosboot -ad/dev/ipldevice
```

- f. After you have made all of your selections, verify that the selections are correct. Press Enter to confirm your selections and to begin the BOS Installation. The system automatically reboots after installation is complete.

__ Step 5. Complete the BOS Installation, as follows:

- a. Type vt100 as the terminal type.

```

                                Set Terminal Type
The terminal is not properly initialized. Please enter a terminal type
and press Enter. Some terminal types are not supported in
non-English languages.

    ibm3101          tvi912          vt330
    ibm3151          tvi920          vt340
    ibm3161          tvi925          wyse30
    ibm3162          tvi950          wyse50
    ibm3163          vs100          wyse60
    ibm3164          vt100          wyse100
    ibmpc            vt320          wyse350
    lft              sun

                                +-----Messages-----+
                                | If the next screen is unreadable, press Break (Ctrl-c)
                                | to return to this screen.
                                |
    88 Help ?
    99 Exit

>>> Choice []: vt100

```

- b. In the License Agreement menu, select **Accept License Agreements**.
- c. Select **yes** to ACCEPT Installed License Agreements.
- d. Press Esc+0 (or F10) to exit the License Agreement menu.
- e. In the Installation Assistant main menu, select **Set Date and Time**.

```

                                Installation Assistant

Move cursor to desired item and press Enter.

Set Date and Time
Set root Password
Set Installation Device
Configure Network Communications
Manage System Storage and Paging Space (rootvg)
Manage Language Environment
Create Users
Define Printers
Import Existing Volume Groups
Install Software Applications
Back Up the System
Using SMIT (information only)
Tasks Completed - Exit to Login

F1=Help           F2=Refresh       F3=Cancel       F8=Image
F9=Shell          F10=Exit         Enter=Do

```

- f. Set the correct date, time, and time zone. Press the F3 (or Esc+3) key to return to the Installation Assistant main menu.
- g. Select **Set root Password**. Set a root password for the partition.
- h. Select **Configure Network Communications**. Select **TCP/IP Startup**. Select from the Available Network Interfaces and press Enter. Enter the appropriate network information in the Minimum Configuration and Startup menu and press Enter. Use the F3 key to return to the Installation Assistant main menu.
- i. Select **Manage System Storage and Paging Space (rootvg)** and press Enter. Select **Add/Show Paging Space** and press Enter. The RECOMMENDED paging space (MB) is calculated based on your partition's resources. If you agree with this calculation, use the value in the NEW paging space (MB) field. Otherwise, you can change the value. Press Enter to accept the value. Use the F3 key to return to the Installation Assistant main menu.

```

                                Add/Show Paging Space

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

MEMORY size (MB)                                [Entry Fields]
DISKS in rootvg                                 64
SPACE available in rootvg (MB)                  hdisk1,hdisk0,hdisk2
RECOMMENDED paging space (MB)                   3604
CURRENT paging space (MB)                       128
NEW paging space (MB)                           64

```

- j. On the Installation Assistant main menu, select **Tasks Completed - Exit to Login**.

Note: You do not need to perform the remaining Installation Assistant tasks at this time.

2. Manage Your Partition (Perform This Step in the AIX Environment)

When the installation has completed and the system has rebooted, the vterm window displays a login prompt. At this point, you may want to perform several common system-administration procedures. The following table lists where to find information about performing these procedures.

Table 8. Common System Administration Procedures

Procedure	Location
Partition Backup and Storage Management	Chapter 5, "System Backup, Dump, and Storage Management" on page 43
Remote Systems Management	Chapter 6, "Remote Management" on page 53
User and Group Management	<i>AIX 5L Version 5.1 System Management Guide: Operating System and Devices</i>
Software Installation	<i>AIX 5L Version 5.1 Installation Guide</i>
Performance Management	<i>AIX 5L Version 5.1 Performance Management Guide</i>
Printer Configuration	<i>AIX 5L Version 5.1 Guide to Printers and Printing</i>

Step-by-Step: Migrating a System to the AIX 5.1 Partition-Ready State

Use this procedure to migrate a separate system from AIX 4.3 or earlier to the latest maintenance level of AIX 5.1. You could then make a system backup (mksysb) of this system, and install this mksysb to a partition or partitions on your managed system.

Prerequisites

Before you begin this procedure, you should have already performed the following tasks:

- The machine on which you are installing must have 64 MB of memory. Machines with less than 64 MB of memory might not be able to boot from the installation media.
- Create a backup of the system. For instructions on how to create a system backup, refer to the Creating System Backups section in the *AIX 5L Version 5.1 Installation Guide*.
- If the system you are installing must communicate with other systems and access their resources, determine the following information for this host: network interface, IP address, host name, and route to the network.

1. Migrate the System to AIX 5.1 (Perform in the AIX Environment)

1. Turn the system unit power switch from Off (O) to On (I). The system begins booting from the installation media.
2. Select the console. If you have more than one console, each might display a screen that directs you to press a key to identify your system console. The *system console* is the keyboard and display device used for installation and system administration. A different key is specified for each console displaying this screen. If this screen displays, press the specified key *only* on the device to be used as the system console. Press a key on one console only.
3. Select the language you prefer to use for installation instructions.
4. When the Welcome to Base Operating System Installation and Maintenance screen displays, select **2 Change/Show Installation Settings and Install** to verify the installation and system settings.
5. Verify the settings for Migration Installation, by following these steps:
 - a. Select **Migration** as the Method of Installation. Select the disk(s) you want to install.

```
1 System Settings:
  Method of Installation.....Migration
  Disk Where You Want to Install.....hdisk0...
```

- b. Select Primary Language Environment Settings (AFTER Install).
- c. Select Advanced Options and press Enter. To learn about the advanced options available, type 88 and press Enter in the Advanced Options menu to use the Help menu.
- d. After you have made all of your selections, verify that the selections are correct and start the Migration Installation process.
- e. When the Migration Confirmation menu displays, follow the menu instructions to list system information or to continue with the migration.

Migration Confirmation

Either type 0 and press Enter to continue the installation, or type the number of your choice and press Enter.

- 1 List the saved Base System configuration files which will not be merged into the system. These files are saved in /tmp/bos.
- 2 List the filesets which will be removed and not replaced.
- 3 List directories which will have all current contents removed.
- 4 Reboot without migrating.

Acceptance of license agreements is required before using system.
You will be prompted to accept after the system reboots.

>>> 0 Continue with the migration.
88 Help ?

+-----+
WARNING: Selected files, directories, and filesets (installable options)
from the Base System will be removed. Choose 2 or 3 for more information.

>>> Choice[0]:

6. After the migration is complete, the system reboots. If the Set Terminal Type menu displays, type vt100 for the terminal type.

Set Terminal Type

The terminal is not properly initialized. Please enter a terminal type and press Enter. Some terminal types are not supported in non-English languages.

ibm3101	tvi912	vt330
ibm3151	tvi920	vt340
ibm3161	tvi925	wyse30
ibm3162	tvi950	wyse50
ibm3163	vs100	wyse60
ibm3164	vt100	wyse100
ibmpc	vt320	wyse350
lft	sun	

88 Help ?
99 Exit

>>> Choice []: vt100

+-----Messages-----
| If the next screen is unreadable, press Break (Ctrl-c)
| to return to this screen.

7. In the License Agreement menu, select **Accept License Agreements**.
8. Select **yes** to ACCEPT Installed License Agreements.
9. Press Esc+0 (or F10) to exit the License Agreement menu.
10. In the Installation Assistant main menu, select **Tasks Completed - Exit to Login**.

Installation Assistant

Move cursor to desired item and press Enter.

Set Installation Device
Manage Language Environment
Install Software Applications
Back Up the System
Using SMIT (information only)
Tasks Completed - Exit to Login

F1=Help
Esc+9=Shell

F2=Refresh
Esc+0=Exit

F3=Cancel
Enter=Do

Esc+8=Image

11. When the login prompt displays, log in as the root user to perform system administration tasks.

2. Manage Your Migrated System (Perform this Step in the AIX Environment)

When the installation has completed and the system has rebooted, the terminal window displays a login prompt.

At this point, you may want to perform several common system-administration procedures. The following table lists where to find information about performing these procedures.

Table 9. Common System Administration Procedures

Procedure	Location
Partition Backup and Storage Management	Chapter 5, "System Backup, Dump, and Storage Management" on page 43
Remote Systems Management	Chapter 6, "Remote Management" on page 53
User and Group Management	<i>AIX 5L Version 5.1 System Management Guide: Operating System and Devices</i>
Software Installation	<i>AIX 5L Version 5.1 Installation Guide</i>
Performance Management	<i>AIX 5L Version 5.1 Performance Management Guide</i>
Printer Configuration	<i>AIX 5L Version 5.1 Guide to Printers and Printing</i>

Step-by-Step: Updating a Partition to the AIX 5.1 Partition-Ready State

Use this procedure to update an existing AIX 5.1 partition to the latest maintenance level of AIX 5.1.

Prerequisites

Before you begin this procedure, you should have already created a backup of the system. For instructions on how to create a system backup, refer to the Creating System Backups section in the *AIX 5L Version 5.1 Installation Guide*.

1. Update Your AIX 5.1 Partition (Perform in the AIX environment)

1. Insert the latest AIX 5.1 update CD into the CD-ROM drive.
2. Update the **bos.rte.install** fileset by using the **geninstall** command as follows:

```
geninstall -d/dev/cd0 bos.rte.install
```

3. Run the **install_all_updates** script, as follows:

```
install_all_updates -d /dev/cd0
```

The **install_all_updates** script will first check if your system is at the latest known recommended maintenance level.

If your system is not at the latest known recommended maintenance level, then the **install_all_updates** script updates the system to the latest maintenance level of AIX.

Note: The output from the **install_all_updates** script is in the **/var/adm/ras/install_all_updates.log** log file.

4. After the update is complete, the system will instruct you to reboot the system. Reboot the system by using the **shutdown** command as follows:

```
shutdown -Fr
```

2. Manage Your Partition (Perform this Step in the AIX Environment)

When the installation has completed and the system has rebooted, the terminal window displays a login prompt.

At this point, you may want to perform several common system-administration procedures. The following table lists where to find information about performing these procedures.

Table 10. Common System Administration Procedures

Procedure	Location
Partition Backup and Storage Management	Chapter 5, "System Backup, Dump, and Storage Management" on page 43
Remote Systems Management	Chapter 6, "Remote Management" on page 53
User and Group Management	<i>AIX 5L Version 5.1 System Management Guide: Operating System and Devices</i>
Software Installation	<i>AIX 5L Version 5.1 Installation Guide</i>
Performance Management	<i>AIX 5L Version 5.1 Performance Management Guide</i>
Printer Configuration	<i>AIX 5L Version 5.1 Guide to Printers and Printing</i>

Step-by-Step: Updating an Existing NIM Environment to the Latest AIX

5.1 Maintenance Level

Use this procedure to update an existing AIX 5.1 NIM environment that was created with the `nim_master_setup` script to the latest maintenance level of AIX 5.1.

Prerequisites

Before you begin this procedure, you should have already created a backup of the system. For instructions on how to create a system backup, refer to the Creating System Backups section in the *AIX 5L Version 5.1 Installation Guide*.

1. Update Your AIX 5.1 NIM Environment to the Latest Maintenance Level (Perform in the AIX Environment)

1. Insert the latest AIX 5.1 update CD into the CD-ROM drive.
2. Update the `bos.rte.install` fileset by using the `geninstall` command as follows:

```
geninstall -d /dev/cd0 bos.rte.install
```

3. Run the `install_all_updates` script, as follows:

```
install_all_updates -d /dev/cd0
```

The `install_all_updates` script will first check if your system is at the latest known recommended maintenance level.

If your system is not at the latest known recommended maintenance level, then the `install_all_updates` script updates the system to the latest maintenance level of AIX.

Note: The output from the `install_all_updates` script is in the `/var/adm/ras/install_all_updates.log` log file.

4. After the update is complete, the system will instruct you to reboot the system. Reboot the system by using the `shutdown` command as follows:

```
shutdown -Fr
```

5. Run the `nim_update_all` script to update the NIM resources that were created by the `nim_master_setup` script, as follows:

```
nim_update_all
```

Output similar to the following displays:

```
##### NIM update all #####  
#  
# During script execution, NIM client and resource updating times      #  
# may vary. To view the install log at any time during nim_update_all,  #  
# run the command: tail -f /var/adm/ras/nim.update in a separate screen. #  
#                                                                        #  
#####
```

```
NSORDER=local,bind  
Adding updates to lpp_res lpp_source....done  
Updating spot_res using updated lpp_source lpp_res....done
```

```
Attempting to replace mkysyb resource generic_sysb...  
Removing old mkysyb resource generic_sysb....done  
Creating image.data file....done  
Checking /export/nim space requirement...
```

```
Generating list of client objects in NIM environment...
```

Note: The `nim_update_all` script will use the device `/dev/cd0` by default. The output from the `nim_update_all` script is shown in the `/var/adm/ras/nim.update` log file.

6. A new generic system backup (mksysb) will be created and will replace the existing mksysb, unless the **-B** flag is specified. *All clients* in the environment will be updated, unless the **-u** flag is specified.

2. Manage Your Partition (Perform this Step in the AIX Environment)

When the installation has completed and the system has rebooted, the terminal window displays a login prompt.

At this point, you may want to perform several common system-administration procedures. The following table lists where to find information about performing these procedures.

Table 11. Common System Administration Procedures

Procedure	Location
Partition Backup and Storage Management	Chapter 5, "System Backup, Dump, and Storage Management" on page 43
Remote Systems Management	Chapter 6, "Remote Management" on page 53
User and Group Management	<i>AIX 5L Version 5.1 System Management Guide: Operating System and Devices</i>
Software Installation	<i>AIX 5L Version 5.1 Installation Guide</i>
Performance Management	<i>AIX 5L Version 5.1 Performance Management Guide</i>
Printer Configuration	<i>AIX 5L Version 5.1 Guide to Printers and Printing</i>

Chapter 5. System Backup, Dump, and Storage Management

Most system backup, dump, and storage management solutions depend on I/O devices. On a partitioned system, I/O devices (such as tape or CD-ROM) are not always available to all partitions. This chapter offers recommended solutions to minimize transfer of I/O devices among partitions.

System Backup

A system backup is a copy of the root volume group (**rootvg**) of your system and is often referred to as a **mksysb**, in reference to the command used to create the system backup. The root volume group contains the following:

- Startup commands
- Base Operating System commands and files
- System configuration information
- Optional software products

All mounted JFS (Journaled File Systems) and JFS2 (Enhanced Journaled File Systems) in the **rootvg** are backed up. Paging space and logical volume information is saved so that the **rootvg** will be re-created as it was when the system backup is reinstalled. If there are JFS or JFS2 file systems that are not to be backed up, you can use an exclude list or you can unmount them before the backup is made.

The following table describes the methods you can use to back up a system.

Table 12. System Backup Methods

Backup Method	Considerations
NIM*	Allows fast backup and recovery of a partition. Because all images are backed up to one system (NIM master), also backs up that system and images to other physical media (tape, CD-RW, DVD-RAM).
mkcd command	Allows creation of a bootable system backup to CD-ROM or DVD-RAM. You can provide an existing mksysb image from another partition if the backup device is not available at the partition being backed up. The mkcd -r command allows backup (not bootable) of images and files to a CD-RW or DVD-RAM.
mksysb command with a tape device	Creates a bootable backup only on the partition the drive is connected to. Must boot from CD or tape to reinstall. Remote tape drives are supported with Sysback (for more information, see http://sysback.services.ibm.com).

* Recommended Method

For more information regarding system backups, refer to the *AIX 5L Version 5.1 Installation Guide*. Other options offered during backup creation are excluding file or directories, as well as creating map files so that the system is restored to exactly the same physical partitions on the disk.

Creating a System Backup

You can create a system backup by using one of the following methods:

Using NIM

With the NIM environment, you can create a system backup that is a selectable resource. That selectable resource can be used to reinstall the partition on which it was created, or it can be cloned to another partition. Because of its flexibility, NIM is the recommended method to back up and reinstall your partitions.

To use NIM to create a system backup, do the following:

1. If your partitions were installed with NIM, go to step 5.
2. On your NIM master, to determine whether your partition is already defined as a NIM client, type:
`lsnim -t standalone`
3. If the target partition is not already a NIM client, configure it by running the following on the target partition:
`smitty nimit`
4. On your NIM master, run the following to define the target partition (the partition to be backed up) as a NIM client:
`smitty nim_mkmac`
5. On your NIM master, type the following to open the Define a Resource menu:
`smitty nim_mkres`
6. Select **mksysb** and type the appropriate information. This menu defines the **mksysb** resource and also creates the system backup image.

Note: Be sure to change CREATE system backup image? to yes.

```
Define a Resource

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

* Resource Name                [Entry Fields]
* Resource Type                [P1_backup]
* Server of Resource           mksysb
* Location of Resource         [master]
Comments                       [/export/nim/mksysb/P1_backup]
                                []

Source for Replication         []
-OR-
System Backup Image Creation Options:
CREATE system backup image?    yes
NIM CLIENT to backup          [system1]
PREVIEW only?                 no
IGNORE space requirements?    no
EXPAND /tmp if needed?        no
Create MAP files?             no
Number of BLOCKS to write in a single output
(leave blank to use system default) []
Use local EXCLUDE file?      no
(specify no to include all files in backup)
-OR-
EXCLUDE_FILES resource       []
(leave blank to include all files in backup)
```

Using CD Media

If you have a CD-RW or DVD-RAM connected to one of your partitions, you can create bootable system backups. You can use the **mkcd** command to create a bootable image on or mount a **mksysb** image to another partition or system that has the device to create and burn the bootable image. Therefore, the device can be assigned to only one partition when creating backup CDs from multiple partitions. To reinstall the systems, you must assign a CD device to the partition being reinstalled.

To create a backup to CD media, do the following:

1. Type:
`smitty mkcd`
You are asked whether you are using an existing **mksysb** image. If you want a backup of this partition, answer No to this question.

If you do use an existing **mksysb** image (possibly from another partition), answer yes. You must enter the location (including the image name) of the existing **mksysb**.

- If you want to save the bootable CD image to burn later, answer No to Create the CD or DVD now?

```

Back Up This System to CD or DVD

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

[TOP]                                [Entry Fields]
CD-R or DVD-R or DVD-RAM Device      []          +
DVD sized image?                      no         +

mksysb creation options:
Create map files?                     no         +
Exclude files?                        no         +

File system to store mksysb image     []          /
  (If blank, the file system
  will be created for you.)

File system to store CD or DVD file structure []      /
  (If blank, the file system
  will be created for you.)

File system to store final CD or DVD images []      /
  (If blank, the file system
  will be created for you.)

If file systems are being created:
Volume Group for created file systems [rootvg]    +

Advanced Customization Options:
Do you want the CD or DVD to be bootable? yes      +
Remove final images after creating CD or DVD? yes  +
Create the CD or DVD now?          no         +
Install bundle file                   []          /
File with list of packages to copy to CD or DVD []      /
Location of packages to copy to CD or DVD []      +/

[MORE...4]
F1=Help          F2=Refresh      F3=Cancel      F4=List
Esc+5=Reset     F6=Command    F7=Edit       F8=Image
F9=Shell        F10=Exit     Enter=Do

```

To burn the CD or DVD at a later time (or to burn additional media), run the following:

```
burn_cd /dev/cd1 /mkcd/cd_images/cd_image_12510
```

The image name `cd_image_12510` includes the process ID. The process ID displays when the **mkcd** command executes.

For further information about creating system backups on CD or DVD, see the *AIX 5L Version 5.1 Installation Guide*, as well as the `/usr/lpp/bos.sysmgt/mkcd.README.txt` file.

Using Tape Media

If you have a tape drive assigned to your partition, you can create a system backup to tape. To create a backup to tape, type the following:

```
smitty mksysb
```

If you want to back up to a file, you can use a separate file system (ensure that you exclude that file system when you create the backup) or a file in a user volume group. For further information about creating a root volume group backup to tape or file, see the *AIX 5L Version 5.1 Installation Guide*.

Installing a System Backup Using NIM

You can use the NIM environment to install a system backup onto one or more of your partitions. NIM is recommended because of its flexibility and customization options for installation and system management. Also, NIM allows for multiple installations at the same time. When you install a system backup onto a partition other than the original partition, you are cloning a partition system image onto a target partition.

Before you can use NIM to install a system backup, make sure that the following are met:

- Your network environment must be working correctly. The NIM master must be configured correctly, and the `lpp_source`, `SPOT`, and `mksysb` resources must be defined. Refer to either the “Step-by-Step: Using a Separate AIX System as a NIM Master to Use NIM to Install Each Partition” on page 16 or the “Step-by-Step: Configuring an Initial Partition as a NIM Master to Use NIM to Install the Remaining Partitions” on page 23 procedures for instructions on setting up NIM in a partitioned environment.
- The target partitions might not contain the same hardware devices or adapters. If this is the case, then the `mksysb`, `SPOT`, and `lpp_source` resources will be needed to install the needed device support.
- Because NIM configures TCP/IP at the end of an installation, it is recommended that a `bosinst_data` resource be allocated for cloning `mksysb` installations with the **RECOVER_DEVICES** field set to **no**. This action prevents the BOS installation process from attempting to configure the devices as they were on the source machine of the `mksysb`.

1. To use a **mksysb** resource to install a NIM client, enter the **smit nim_bosinst** fast path.
2. Select a **TARGET** for the operation.

```
                Select a TARGET for the operation

Move cursor to desired item and press Enter.

lpar1   machines   standalone
lpar2    machines    standalone
lpar3    machines    standalone
```

3. Select **mksysb** as the installation TYPE.

```
                Select the installation TYPE

Move cursor to desired item and press Enter.

rte - Install from installation images
spot - Perform a SPOT copy
mksysb - Install from a mksysb
```

4. Select the **mksysb** to use for the installation.

```
                Select the MKSYSB to use for the installation

Move cursor to desired item and press Enter.

generic_sysb   resources   mksysb
lpar5_sysb      resources    mksysb
```

5. Select the **SPOT** to use for the installation.

```
                Select the SPOT to use for the installation

Move cursor to desired item and press Enter.

510spot_res   resources   spot
433spot_res    resources    spot
```

6. Select the **lpp_source** to use for the installation.

```

Select the LPP_SOURCE to use for the installation

Move cursor to desired item and press Enter.

510lpp_res    resources    lpp_source
433lpp_res    resources    lpp_source

```

7. The Install the Base Operating System on Standalone Clients panel looks similar to the following:

```

Install the Base Operating System on Standalone Clients

Type or select values in entry fields.
Press Enter AFTER making all desired changes.
[TOP]
* Installation Target          [Entry Fields]
* Installation TYPE            1par1
* SPOT                         mksysb
* LPP_SOURCE                   510spot_res
MKSYSB                        510lpp_res
                               generic_sysb

BOSINST_DATA to use during installation  []      +
IMAGE_DATA to use during installation    []      +
RESOLV_CONF to use for network configuration []    +
Customization SCRIPT to run after installation []  +
Customization FB Script to run at first reboot []  +
ACCEPT new license agreements?          [no]   +
Remain NIM client after install?        [yes]   +
[MORE...35]

```

8. Select a **bosinst_data** resource to perform a non-prompted installation. Select the **bid_tty_ow** resource if the partition does not have a graphics adapter and an low frequency terminal (lft).

```

BOSINST_DATA to use during installation

Move cursor to desired item and press Enter.

bid_tty_ow    resources    bosinst_data
bid_lft_ow    resources    bosinst_data

```

9. Select a **resolv_conf** resource to establish network configuration for the client partition.

```

RESOLV_CONF to use for network configuration

Move cursor to desired item and press Enter.

resolv_res    resources    resolv_conf

```

- 10. Set the Accept new License Agreements field to **yes**
- 11. The Install the Base Operating System on Standalone Clients menu looks similar to the following:

Install the Base Operating System on Standalone Clients

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

```
[TOP]
* Installation Target          [Entry Fields]
* Installation TYPE           1par1
* SPOT                        mksysb
* LPP_SOURCE                  spot_res
  MKSYSB                     lpp_res
                             generic_sysb

BOSINST_DATA to use during installation  [bid_lft_ow]          +
IMAGE_DATA to use during installation    []                   +
RESOLV_CONF to use for network configuration [resolv_res]        +
Customization SCRIPT to run after installation []                +
Customization FB Script to run at first reboot []                +
  ACCEPT new license agreements?        [yes]                +
Remain NIM client after install?        [yes]                +
PRESERVE NIM definitions for resources on this target? [yes]                +

FORCE PUSH the installation?           [no]                 +

Initiate reboot and installation now?   [yes]                +
-OR-
Set bootlist for installation at the next reboot? [no]                 +

Additional BUNDLES to install          []                   +
-OR-
Additional FILESETS to install         []                   +
(bundle will be ignored)

[MORE...20]
```

12. Press Enter to install the NIM client.
13. If the client partition being installed is not already a running, configured NIM client, NIM will not automatically reboot the machine over the network for installation. If the client was not rebooted automatically from SMIT, initiate a network boot from the client to install it. For instructions on how to do this procedure, refer to “2. Activate and Install Partitions (Perform These Steps in the HMC Interface)” on page 19.

System Dump Management

If your machine has more than 4 GB of real memory, a dedicated dump device is created at installation time. Otherwise, the `/dev/hd6` paging space is used as the dump device. If a system crash occurs and paging space was used as the dump device, the dump is copied to the `/var/adm/ras/vmcore.n` file by default, where `n` is a sequence number. If there is not enough space to perform the copy, the user is prompted during reboot to save the dump to some other media.

To avoid losing a dump due to a lack of a tape drive configured to the partition, always create a separate dump device that is the same size as your paging space, given that paging space is currently your dump device.

To verify your dump device, type `smitty dump`, and select **Show Current Dump Devices**. If paging space is your dump device, the output will be similar to the following:

COMMAND STATUS

Command: OK stdout: yes stderr: no

Before command completion, additional instructions may appear below.

```
primary                /dev/hd6
secondary              /dev/sysdumpnull
copy directory        /var/adm/ras
forced copy flag      TRUE
always allow dump     FALSE
dump compression     OFF
```

To create and change to a dedicated dump device, do the following:

1. Determine the size of the hd6 paging space (in logical partitions) by running the following:

```
# lsvg -l rootvg
```

The output will be similar to the following:

```
rootvg:
LV NAME                TYPE            LPs    PPs    PVs    LV STATE        MOUNT POINT
hd5                    boot            2      2      1      closed/syncd    N/A
hd6                    paging          53     53     1      open/syncd      N/A
hd8                    jfslog          1      1      1      open/syncd      N/A
hd4                    jfs             9      9      1      open/syncd      /
hd2                    jfs             130    130    1      open/syncd      /usr
hd9var                 jfs             2      2      1      open/syncd      /var
hd3                    jfs             8      8      1      open/syncd      /tmp
hd1                    jfs             1      1      1      open/syncd      /home
hd10opt                jfs             5      5      1      open/syncd      /opt
```

In the preceding example, the paging space is 53 LPs (logical partitions) in size.

2. To create a dump logical volume, type:

```
smitty mklv
```

When you are prompted for the volume group, type rootvg.

3. In the next menu, fill in the **Logical volume NAME** and the **Number of LOGICAL PARTITIONS** fields. Type dump for logical volume type. Press Enter after you make your selections.

```

                                Add a Logical Volume

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

Logical volume NAME                [Entry Fields]
* VOLUME GROUP name                [dumplv]
* Number of LOGICAL PARTITIONS     [53] #
PHYSICAL VOLUME names              [hdisk0] +
Logical volume TYPE                [dump]
POSITION on physical volume        middle +
RANGE of physical volumes          minimum +
MAXIMUM NUMBER of PHYSICAL VOLUMES [ ] #
to use for allocation
Number of COPIES of each logical   1 +
partition
Mirror Write Consistency?          active +
Allocate each logical partition copy on a SEPARATE physical volume? yes +
RELOCATE the logical volume during reorganization? yes +
Logical volume LABEL               [ ]
MAXIMUM NUMBER of LOGICAL PARTITIONS [512] #
Enable BAD BLOCK relocation?       yes +
SCHEDULING POLICY for reading/writing logical partition copies parallel +
Enable WRITE VERIFY?               no +
File containing ALLOCATION MAP      [ ]
Stripe Size?                       [Not Striped] +

```

4. To change the primary dump device, type:
 smitty dumpchgp

You will be prompted for the new dump device.

```

                                Change Primary Dump Device

Type or select values in entry fields.
Press Enter AFTER making all desired changes.

* Primary dump device              [Entry Fields]
                                   [ /dev/dumplv ]

```

5. To validate your dump devices, type the following:
 smitty dump

Select **Show Current Dump Devices**. The output will be similar to the following:

```

                                COMMAND STATUS

Command: OK          stdout: yes          stderr: no

Before command completion, additional instructions may appear below.

primary              /dev/dumplv
secondary           /dev/sysdumpnull
copy directory      /var/adm/ras
forced copy flag    TRUE
always allow dump   FALSE
dump compression    OFF

```

Storage Management

If you have multiple **mksysb** images stored on a NIM master (or on some other partition), you can use the **mkcd -r** command to store them to CD-R or DVD-RAM. The images to be written to CD-R or DVD-RAM must be in one directory structure, so that a directory can be passed to the **mkcd** command as the starting point of the backup.

The usage for the **mkcd** command, is as follows:

```
Usage: mkcd {-d cd_device} [-r directory] [-R | -S] [-I cd_image_dir] [-D] [-L]
```

Where:

- d** Specifies the CD-R or DVD-RAM device
- S** Indicates to stop the backup before burning the image (image can be burned at a later time)
- r** Specifies the directory from which to create your CD image
- I** Specifies the directory in which to write the CD image
- R** Saves the CD images (use this flag if you want to burn multiple copies)
- D** Enables debugging for the **mkcd** command
- L** Creates final CD images that are DVD-sized (up to 4.38 GB)

For example, to back up the stored **mksysb** images in the **/export/nim/mksysbs** to a DVD-RAM device (**/dev/cd1**), and use a temporary file system mounted on **/largefilesystem** to use as temporary CD image storage, type the following:

```
# mkcd -d /dev/cd1 -r /export/nim/mksysbs -I /largefilesystem -L
```

To verify the **mksysb**, run the following commands:

```
# mount -o ro /dev/cd0/mnt
# cd /mnt
# ls
```

Chapter 6. Remote Management

This chapter discusses how you can use the Hardware Management Console (HMC) to manage your system remotely. For information on the commands you can use to remotely manage partitions through the command line on the HMC, see the *IBM IBM Hardware Management Console for pSeries Operations Guide*.

Some of the system management methods are as follows. Each of these methods can be performed by using the HMC interface or from the command line.

- Use the HMC client to remotely manage any AIX partition or system. All AIX plug-ins on the AIX system can be managed remotely from the HMC client, provided that the Web-based System Manager framework version is compatible. The operating system checks each plug-in for compatibility with the Web-based System Manager framework. If it is not compatible for that plug-in, a message displays, indicating that the plug-in cannot be managed by the client.
- Use an AIX partition or system to remotely manage an HMC. All HMC plug-ins on the HMC server may be managed remotely from the AIX system, provided that the AIX system is at a compatible Web-based System Manager framework version. Otherwise, an error message displays indicating that the AIX system cannot manage the HMC server.
- Use a Web-based System Manager PC client to remotely manage an HMC server. For instructions on how to install the PC client, refer to the *AIX 5L Version 5.1 Web-based System Manager Administration Guide*. All HMC plug-ins on the HMC server may be managed remotely from the PC client, provided that the PC client is at a compatible Web-based System Manager framework version. Otherwise, an error message displays indicating that the PC Client cannot manage the HMC server. The only plug-in that is an exception to this is the Service Agent plug-in.
- Use an HMC client to remotely manage another HMC client. All HMC plug-ins on the HMC server may be managed remotely from the HMC client. The only plug-in that is an exception to this is the Service Agent plug-in.

Note: When remotely managing the HMC, the command-line tasks you can perform are limited to configuration tasks.


For more information on remote management, see either of the following README files:

- /usr/websm/readme.html
- /usr/websm/readme.txt

Remote Management From the HMC to AIX Partitions


- After the partition is configured on the network, you can add the partition as a host in the HMC interface, as follows:

1. Select **Console -> Add -> Hosts**.



2. Type the host name of the partition to add. The host will be added to the list.

- After the partition is configured on the network, you can open an xterm window to connect to the partition within the HMC interface by selecting **Console -> Open Terminal**. Enter either the host name or the IP address of the system.



Chapter 7. Hints and Tips

This chapter provides hints and tips to help you when working with AIX in a partitioned environment.

Naming Your Operating System Host Name

Each partition, including the Full System Partition, must have a unique host name that can be resolved. Host names cannot be reused between the Full System Partition and the logical partitions.

If the host name of the partition must be changed, before changing the host name of the partition, do the following:

1. If your system's level of AIX is earlier than the 5100-02 maintenance package level, skip this step and go to step 2.

```
/usr/sbin/rsct/bin/runact -c IBM.ManagementServer SetRTASPollingInterval Seconds=0
```

2. Run the following command:

```
/usr/sbin/rsct/bin/lsrc IBM.ManagementServer Hostname
```

If the partition is managed by multiple HMCs, there may be multiple entries, because each HMC has its own entry. The output will be similar to the following.

```
resource 1:  
  Hostname      = "hmc1.mydomain.mycompany.com"
```

3. For each entry, remove the resource using the host name shown. For example, run the following command:

```
/usr/sbin/rsct/bin/rmrsrc -s 'Hostname = "hmc1.mydomain.mycompany.com"' IBM.ManagementServer
```

You can verify that all entries have been removed by running Step 2 again.

4. Run the following command:

```
/usr/sbin/rsct/bin/rmctr1 -z
```

5. Change the host name of the partition.

6. After the host name has been changed, run the following command:

```
/usr/sbin/rsct/bin/rmctr1 -A
```

For information on updating the partition information on the HMC, see the *IBM IBM Hardware Management Console for pSeries Operations Guide*, order number SA38-0590-01.

Network Adapter Communication Between Partitions and the HMC

After a partition has been started, it uses the network adapter to communicate with the HMC. Both the HMC and the partition must be configured so they can use the network adapters to communicate with each other. The partition must be configured to identify the HMC (or HMCs) on the network. It is recommended that the network be configured using a Domain Name Service (DNS) server.

You can use either fully qualified host names or short host names to identify partitions and HMCs. However, it is recommended that each partition and HMC be identified using a fully qualified host name, as this identification ensures uniqueness of all the partitions and the HMC in the network. Fully qualified host names cannot be more than 100 bytes in length.

The HMC and partitions can also be configured using a "short" host name, where the domain name is not defined. This is typically done in a private or test network. If the HMC is defined using a "short" host name, you must perform extra network configuration steps to ensure correct communications between the

partitions and the HMC. If you use short host names rather than fully qualified host names, you should make sure that the short host names are unique and that the mappings to IP addresses are properly specified.

The search order between the local **/etc/hosts** file and the DNS can be specified using the **/etc/netsvc.conf** file or **/etc/irs.conf** file.

The following examples illustrate the scenarios supported:

- If you are using DNS and your partition and the HMC are using fully qualified host names, then no additional network configuration is required.
- If you are using DNS and your partition is using a short host name, such as `partition_1` and the HMC is also using a short host name, such as `hmc123`, then both need to be added to the local **/etc/hosts** file, as shown below:

```
root@partition_1
-> cat /etc/hosts

127.0.0.1 loopback localhost
```

```
9.3.3.151 partition_1
9.3.3.152 hmc123
```

- If you are not using DNS and your partition is using a fully qualified host name, such as `partition_1.mydomain.mycompany.com`, and the HMC is also using a fully qualified host name, such as `hmc123.mydomain.mycompany.com`, then both need to be added to the local **/etc/hosts** file, as shown below:

```
root@partition_1.mydomain.mycompany.com
-> cat /etc/hosts

127.0.0.1 loopback localhost
```

```
9.3.3.151 partition_1.mydomain.mycompany.com
9.3.3.152 hmc123.mydomain.mycompany.com
```

- If you are not using DNS and your partition is using a short host name, such as `partition_1` and the HMC is also using a short host name, such as `hmc123`, then both need to be added to the local **/etc/hosts** file, as shown below:

```
root@partition_1
-> cat /etc/hosts

127.0.0.1 loopback localhost
```

```
9.3.3.151 partition_1
9.3.3.152 hmc123
```

- Your HMC is using a short host name, such as `hmc123`, and you would like to use both a fully qualified host name and a short host name for the HMC. Then in order for your partition to correctly communicate with the HMC, you must specify the short host name before the fully qualified host name in the partition's **/etc/hosts** file.

```
root@partition_1.mydomain.mycompany.com
-> cat /etc/hosts

127.0.0.1 loopback localhost
```

```
9.3.3.151 partition_1.mydomain.mycompany.com
9.3.3.152 hmc123 hmc123.mydomain.mycompany.com
```

Shutting Down a Partition

This section provides information on how to shut down a partition using the HMC and using AIX.

Using AIX to Shut Down a Partition

When a partition is up, it is in the *Running* state. To use AIX to shut down an LPAR, do the following:

1. On the AIX command prompt, type `shutdown -Fr` to restart AIX.
2. The partition eventually changes to the *Starting* state, and the operator panel values display, which indicates AIX is now rebooting.
3. When the reboot is issued within AIX, the partition will boot according to the contents of the bootlist. To check the order of the boot devices, type `bootlist -m normal -o`
4. To shut down AIX, on the AIX command prompt, type `shutdown -F`.

The partition will eventually change to the *Ready* state. You have now shut down AIX and its partition.

To start AIX, on the HMC, select **Activate**. When you select **Activate**, the HMC uses the boot mode selection in the partition profile.

Using the HMC Interface to Shut Down a Partition

To use the HMC to shut down a partition, do the following:

1. Select the partition you want to shut down.
2. Right-click on the partition to open the menu.
3. Select **Operating System Reset**.
4. Select **Hard Reset**. This action sends a **halt** signal indicating which instance of AIX is to be shut down. If a vterm window was open while the hard reset was done, the vterm window remains open. The partition will then be in a *Ready* state.

To activate the partition, select the partition and press the right mouse button. Select **Activate**. When you select **Activate**, the HMC uses the boot mode selection in the partition profile.

Closing a vterm window does not shut down an partition. However, closing the window logs you off that session and kills any processes that you are running from that vterm window.

Appendix. Notices

This information was developed for products and services offered in the U.S.A. IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service. IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing
IBM Corporation
North Castle Drive
Armonk, NY 10504-1785
U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

IBM World Trade Asia Corporation
Licensing
2-31 Roppongi 3-chome, Minato-ku
Tokyo 106, Japan

The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law: INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you. This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

IBM Corporation
Dept. LRAS/Bldg. 003
11400 Burnet Road
Austin, TX 78758-3498
U.S.A.

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and

cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

Index

A

- about this book v
- affinity logical partitions 5
- AIX
 - shutting down 56
- alt_disk_install 13
- alternate disk installation 13

B

- backing up
 - system 43
 - to CD media 43
 - to tape media 43
 - with NIM 43
- backing up to CD media 44
- backing up to tape media 45
- backing up with NIM 43
- backup
 - considerations 43
 - system 43
- backups
 - creating using NIM 43
 - system
 - creating 43
 - to CD 44
 - to tape 45

C

- communication between HMC and Partitions 55
- configuring online documentation 4
- consolidation of multiple versions of the same operating system 8
- creating a system backup 43

D

- documentation
 - online
 - configuring 4
 - installing on a server 4
 - installing on a system 4
 - viewing from the CD 4
- documentation overview
 - documentation web site 2
- dumps
 - system
 - logical volume 48
 - managing 48

E

- eServer pSeries materials list 2

G

- Getting Started 1

H

- Hardware Management Console 53
- highlighting used v
- HMC
 - see Hardware Management Console 53
- host name
 - naming 55

I

- installation scenarios 12
- installing a system backup
 - using NIM 46
- installing AIX
 - configuring an initial LPAR as a NIM master 23
 - considerations 15
 - migrating a system to the AIX 5.1 partition-ready state 36, 39, 40
 - overview 9
 - procedures 15
 - using a separate AIX system as a NIM master 16
 - using the CD to manually install a logical partition 30
- installing AIX in an LPAR environment 15
- installing AIX in an partitioned environment 15
- introduction to Network Installation Management 9
- ISO 9000 v

L

- logical partition
 - consolidation of multiple versions of the same operating system 8
 - logical partition overview 5
 - minimum resources 5
 - mixed production and test environments 7
 - overview 5
 - roadmap 7
 - scenarios and recommendations 9
 - server consolidation 7
 - when to implement 7
 - working with 6
- LPAR
 - see logical partition 5
- LPP_Source directory 9

M

- managed system 5
- materials list
 - eServer pSeries 2
- mkcd 43, 44, 45

mksysb 43

N

naming your OS host 55
Network Adapter Communication Between Partitions
and the HMC 55
Network Installation Management
introduction 9
Network Installaton Management
installation scenarios 12
NIM
see Network Installation Management 9
NIM resources
bosinst_data 9
LPP_Source 9
mksysb 9
resolv_conf 9
resource group 9
SPOT 9

O

online documentation 2
overview
documentation 2
overview of AIX installation process 9
overview of partitions
affinity logical partition 5
affinity partition 5
full system partition 5
managed system 5

P

Partition Scenarios
Adding Your Managed System to an RS/6000 SP
Environment 13
Advanced Installation Options 13
First AIX System in Your Environment 12
Installing a Partition Using Alternate Disk
Installation 13
Migrating to AIX 5.1 and Configuring Partition
Support 12
Updating an Existing AIX 5.1 System 12
publications
online 2, 22
related 2, 22

R

README
README.PARTITION_INSTALL 13
related publications v
remote management 53
from the HMC 53
to AIX partitions 53
Roadmap, Partition 1

S

scenarios and recommendations
logical partition 9
shutting down a logical partition 56
shutting down a partition
using AIX 57
using the HMC 57
SP environment 13
storage management 51
Sysback 43
system backup 43
system backup, dump and storage management 43
system dump management 48

T

trademarks vi

W

who should use this book v



Part Number: 09P6532

Printed in U.S.A.

SC23-4382-01



(1P) P/N: 09P6532

